



# **Owner's Manual**

## **Original Instructions**

Commercial Air Conditioners

## Heat Recovery DC Inverter VRF

Models:

GMV-Q72WM/B-U(U)

GMV-Q96WM/B-U(U)

GMV-Q120WM/B-U(U)

.....

GMV-Q360WM/B-U(U)


Thank you for choosing commercial air conditioners. Please read this Owner's Manual carefully before operation and retain it for future reference.

If you have lost the Owner's Manual, please contact the local agent or visit [www.gree.com](http://www.gree.com) or send an email to [global@cn.gree.com](mailto:global@cn.gree.com) for the electronic version.

**GREE ELECTRIC APPLIANCES, INC. OF ZHUHAI**

## Preface

Gree DC Inverter Multi VRF System, with the most advanced technologies in the world, uses eco-friendly refrigerant R410A as its cooling medium. For correct installation and operation, please read this manual carefully.

|   |  |
|---|--|
|  | This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death. |
| <b>⚠WARNING</b>   | This mark indicates procedures which, if improperly performed, might lead to the death or serious injury of the user.  |
| <b>⚠CAUTION</b>   | This mark indicates procedures which, if improperly performed, might possibly result in personal harm to the user, or damage to property.  |
| <b>NOTICE!</b>  | NOTICE is used to address practices not related to personal injury.  |

| <b>⚠WARNING</b> |   |
|-----------------|---|
|                 | (1) Instructions for installation and use of this product are provided by the manufacturer.   |
|                 | (2) Installation must be performed in accordance with the requirements of NEC and CEC by authorized personnel only.   |
|                 | (3) For safety operation, please strictly follow the instructions in this manual.   |
|                 | (4) During operation, the gross rated capacity of working IDU should be within the gross rated capacity of ODU. Otherwise, IDU's cooling/heating performance will be reduced.   |
|                 | (5) This manual must be in the hands of direct operators or maintenance men.  |
|                 | (6) In case of malfunction and operation failure, please examine the following items and contact our authorized service centers as soon as possible.<br>1) Nameplate (model, cooling capacity, product code, ex-factory date).<br>2) Malfunction status (detail description of conditions before and after malfunction occurs). |
|                 | (7) All units have been strictly tested and proved to be qualified before ex-factory. To avoid unit damage or even operation failure which may be caused by improper disassembly, please do not disassemble units by yourself. If disassembly is needed, please contact our authorized service centers for help.                |
|                 | (8) All graphics and information in this manual are only for reference. Manufacturer reserves the right for changes in terms of sales or production at any time and without prior notice.   |
|                 | (9) If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.  |

This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance. Cleaning and user maintenance shall not be made by children without supervision.



**DISPOSAL:** Do not dispose this product as unsorted municipal waste. Collection of such waste separately for special treatment is necessary.



## Exception Clauses

Manufacturer will bear no responsibilities when personal injury or property loss is caused by the following reasons:

- (1) Damage the product due to improper use or misuse of the product;
- (2) Alter, change, maintain or use the product with other equipment without abiding by the instruction manual of manufacturer;
- (3) After verification, the defect of product is directly caused by corrosive gas;
- (4) After verification, defects are due to improper operation during transportation of product;
- (5) Operate, repair, maintain the unit without abiding by instruction manual or related regulations;
- (6) After verification, the problem or dispute is caused by the quality specification or performance of parts and components that produced by other manufacturers;
- (7) The damage is caused by natural calamities, bad using environment or force majeure.

# Contents

|   |    |
|---|----|
| 1 Safety Precautions .....  | 1  |
| 2 Product Introduction .....                                      | 2  |
| 2.1 Names of Main Parts .....                                     | 2  |
| 2.2 Combinations of Outdoor Units .....                           | 2  |
| 2.3 Combinations of Indoor and Outdoor Units .....                | 3  |
| 2.4 The Range of Production Working Temperature .....             | 4  |
| 3 Preparation before Installation .....                           | 4  |
| 3.1 Standard Parts .....  | 4  |
| 3.2 Installation Site .....                                       | 4  |
| 3.3 Piping Work Requirements.....                                 | 11 |
| 4 Installation Instruction .....                                  | 11 |
| 4.1 ODU Foundation .....  | 11 |
| 4.2 Physical Dimension of the Outdoor Unit and Mounting Hole..... | 12 |
| 4.3 Connection Pipe.....  | 13 |
| 4.4 Installation of the Connection Pipe .....                     | 22 |
| 4.5 Air Purging and Refrigerant Charge.....                       | 26 |
| 4.6 Electric Wiring .....   | 29 |
| 4.7 System Communication .....                                    | 31 |
| 4.8 Connection Method and Steps for System Communication .....    | 36 |
| 4.9 External Electrical Wiring Diagram .....                      | 41 |
| 5 Check Items after Installation and Trial Run .....              | 42 |
| 5.1 Check Items after Installation.....                           | 42 |
| 5.2 Trial Run.....  | 42 |
| 6 Common Malfunction and Troubleshooting .....                    | 54 |
| 7 Error Indication .....  | 56 |
| 8 Maintenance and Care .....                                      | 60 |
| 8.1 Outdoor Heat Exchanger .....                                  | 60 |
| 8.2 Drain Pipe .....  | 60 |
| 8.3 Notice before Seasonal Use .....                              | 61 |
| 8.4 Maintenance after Seasonal Use.....                           | 61 |
| 8.5 Parts Replacement.....  | 61 |
| 9 After-sales Service .....                                       | 61 |

# 1 Safety Precautions

| <b>⚠WARNING</b>  |
|--|
| (1) This product can't be installed at corrosive, inflammable or explosive environment or the place with special requirements, such as kitchen. Otherwise, it will affect the normal operation or shorten the service life of the unit, or even cause fire hazard or serious injury. As for above special places, please adopt special air conditioner with anti-corrosive or anti-explosion function. |
| (2) Follow this instruction to complete the installation work. Please carefully read this manual before unit startup and service.  |
| (3) Wire size of power cord should be large enough. The damaged power cord and connection wire should be replaced by exclusive cable.  |
| (4) After connecting the power cord, please fix the electric box cover properly in order to avoid accident.  |
| (5) Never fail to comply with the nitrogen charge requirements. Charge nitrogen when welding pipes.  |
| (6) Never short-circuit or cancel the pressure switch to prevent unit damage.  |
| (7) Please firstly connect the wired controller before energization, otherwise wired controller cannot be used.  |
| (8) Before using the unit, please check if the piping and wiring are correct to avoid water leakage, refrigerant leakage, electric shock, or fire etc.   |
| (9) Do not insert fingers or objects into air outlet/inlet grille.   |
| (10) Open the door and window and keep good ventilation in the room to avoid oxygen deficit when the gas/oil supplied heating equipment is used.   |
| (11) Never start up or shut off the air conditioner by means of directly plug or unplug the power cord.  |
| (12) Turn off the unit after it runs at least five minutes; otherwise it will influence oil return of the compressor.  |
| (13) Do not allow children operate this unit.  |
| (14) Do not operate this unit with wet hands.  |
| (15) Turn off the unit or cut off the power supply before cleaning the unit, otherwise electric shock or injury may happen.  |
| (16) Never spray or flush water towards unit, otherwise malfunction or electric shock may happen.  |
| (17) Do not expose the unit to the moist or corrosive circumstances.   |
| (18) Under cooling mode, please don't set the room temperature too low and keep the temperature difference between indoor and outdoor unit within 5°C (41°F).  |
| (19) User is not allowed to repair the unit. Fault service may cause electric shock or fire accidents. Please contact Gree appointed service center for help.  |
| (20) Before installation, please check if the power supply is in accordance with the requirements specified on the nameplate. And also take care of the power safety.  |
| (21) Installation should be conducted by dealer or qualified personnel. Please do not attempt to install the unit by yourself. Improper handling may result in water leakage, electric shock or fire disaster etc.   |
| (22) Be sure to use the exclusive accessory and part to prevent the water leakage, electric shock and fire accidents.  |
| (23) Make sure the unit can be earthed properly and soundly after plugging into the socket so as to avoid electric shock. Please do not connect the ground wire to gas pipe, water pipe, lightning rod or telephone line.  |
| (24) Electrify the unit 8 hours before operation. Please switch on for 8 hours before operation. Do not cut off the power when 24 hours short-time halting (to protect the compressor).  |
| (25) If refrigerant leakage happens during installation, please ventilate immediately. Poisonous gas will emerge if the refrigerant gas meets fire.  |
| (26) Volatile liquid like thinner or gasoline will damage the appearance of air conditioner. Please use soft dry cloth or wet cloth with mild detergent to clean the outer case of air conditioner.  |
| (27) If anything abnormal happens (such as burning smell), please power off the unit and cut off the main power supply, and then immediately contact Gree appointed service center. If abnormality keeps going, the unit might be damaged and lead to electric shock or fire.  |

GREE will not assume responsibility of personal injury or equipment damage caused by improper installation and commission, unnecessary service and incapable of following the rules and instructions listed in this manual.

## 2 Product Introduction

Gree Multi VRF System adopts inverter compressor technology. According to change the displacement of compressor, stepless capacity regulation within range of 10%-100% can be realized. Various product lineup is provided with capacity range from 72kBtu/h to 360kBtu/h, which can be widely used in working area and especially applicable to the place with variable load change. Gree air conditioner is absolutely your best choice.

### 2.1 Names of Main Parts




Fig.2.1.1

| No.  | ①          | ②                     | ③               | ④                       | ⑤                               |
|------|------------|-----------------------|-----------------|-------------------------|---------------------------------|
| Name | Fan, Motor | Electric Box Assembly | Valve interface | Power cord through-hole | Communication code through-hole |

### 2.2 Combinations of Outdoor Units

|                  |  |  |  |
|------------------|--|--|--|
| Model (Single)   | GMV-Q144WM/B-U(U)                      | GMV-Q168WM/B-U(U)                      | GMV-Q192WM/B-U(U)                      |
| Model (Combined) | GMV-Q72WM/B-U(U)<br>+ GMV-Q72WM/B-U(U) | GMV-Q72WM/B-U(U)<br>+ GMV-Q96WM/B-U(U) | GMV-Q96WM/B-U(U)<br>+ GMV-Q96WM/B-U(U) |

|                  |   |  |  |
|------------------|---|--|--|
| Model (Single)   | GMV-Q216WM/B-U(U)                       | GMV-Q240WM/B-U(U)                        | GMV-Q264WM/B-U(U)  |
| Model (Combined) | GMV-Q96WM/B-U(U)<br>+ GMV-Q120WM/B-U(U) | GMV-Q120WM/B-U(U)<br>+ GMV-Q120WM/B-U(U) | GMV-Q72WM/B-U(U)<br>+ GMV-Q96WM/B-U(U)<br>+ GMV-Q96WM/B-U(U) |

|                  |  |   |  |
|------------------|--|---|--|
| Model (Single)   | GMV-Q288WM/B-U(U)  | GMV-Q312WM/B-U(U)   | GMV-Q336WM/B-U(U)  |
| Model (Combined) | GMV-Q96WM/B-U(U)<br>+ GMV-Q96WM/B-U(U)<br>+ GMV-Q96WM/B-U(U) | GMV-Q96WM/B-U(U)<br>+ GMV-Q96WM/B-U(U)<br>+ GMV-Q120WM/B-U(U) | GMV-Q96WM/B-U(U)<br>+ GMV-Q120WM/B-U(U)<br>+ GMV-Q120WM/B-U(U) |

|                  |   |
|------------------|---|
| Model (Single)   | GMV-Q360WM/B-U(U)   |
| Model (Combined) | GMV-Q120WM/B-U(U)<br>+ GMV-Q120WM/B-U(U)<br>+ GMV-Q120WM/B-U(U) |

### 2.3 Combinations of Indoor and Outdoor Units

| ODU Model         | Max number of connectable IDU (unit) | ODU Model         | Max number of connectable IDU (unit) |
|-------------------|--------------------------------------|-------------------|--------------------------------------|
| GMV-Q72WM/B-U(U)  | 13                                   | GMV-Q240WM/B-U(U) | 39                                   |
| GMV-Q96WM/B-U(U)  | 16                                   | GMV-Q264WM/B-U(U) | 46                                   |
| GMV-Q120WM/B-U(U) | 19                                   | GMV-Q288WM/B-U(U) | 50                                   |
| GMV-Q144WM/B-U(U) | 23                                   | GMV-Q312WM/B-U(U) | 53                                   |
| GMV-Q168WM/B-U(U) | 29                                   | GMV-Q336WM/B-U(U) | 56                                   |
| GMV-Q192WM/B-U(U) | 33                                   | GMV-Q360WM/B-U(U) | 59                                   |
| GMV-Q216WM/B-U(U) | 36                                   | —                 | —                                    |

The total capacity of indoor units should be within 50%~135% of that of outdoor units.




Fig.2.3.1

Fig.2.3.1 is the combination view of the ODU of Modular DC Inverter Multi VRF System and the

IDU of Multi VRF System. IDU can be cassette type, one-way cassette type, wall-mounted type, duct type, etc. When any one IDU receives operation signal, ODU will start to work according to the capacity; when all IDUs stop, ODU will also stop.

## 2.4 The Range of Production Working Temperature

|                         |   |
|-------------------------|---|
| Cooling operation       | Ambient temperature: -5°C(23°F)~52°C(125.6°F) |
| Heating operation       | Ambient temperature: -20°C(-4°F)~24°C(75.2°F) |
| Heat recovery operation | Ambient temperature:-10°C(14°F)~20°C(68°F)    |

When the indoor units are all VRF fresh air indoor units, the unit operating range is as follows:

|                   |  |
|-------------------|--|
| Cooling operation | Ambient temperature: 16°C(60.8°F)~45°C(113°F)  |
| Heating operation | Ambient temperature: -7°C(19.4°F)~16°C(60.8°F) |



**NOTICE!** Out of the working Temperature Range may damage this product and will invalidate the warranty.

## 3 Preparation before Installation

**NOTICE!** The picture is only used for reference and the actual product prevails. Unit: mm (inch).

### 3.1 Standard Parts

Please use the following standard parts supplied by Gree.

| Parts for Outdoor Unit |                                |   |          |   |
|------------------------|--------------------------------|---|----------|---|
| Number                 | Name                           | Picture   | Quantity | Remarks   |
| 1                      | Owner's Manual                 |  | 1        | —   |
| 2                      | Wiring (match with resistance) |  | 1        | Must be connected to the last IDU of communication connection |

### 3.2 Installation Site

| <b>⚠WARNING</b>   |
|---|
| (1) Install the unit at a place where is adequate to withstand the weight of the unit and make sure the unit would not shake or fall off. |
| (2) Never expose the unit under direct sunshine and rainfall. Install the unit at a place where is against dust, typhoon and earthquake.  |
| (3) Try to keep the unit away from combustible, inflammable and corrosive gas or exhaust gas.   |
| (4) Leave some space for heat exchanging and servicing so as to guarantee unit normal operation.  |
| (5) Keep the indoor and outdoor units close to each other as much as possible so as to decrease the pipe length and bends.                |
| (6) Never allow children to approach to the unit and take measures to prevent children touching the unit.                                 |



3.2.1 When the outdoor unit is totally surrounded by walls, please refer to following figures for space dimension.

3.2.1.1 Space dimension for single-module unit

Unit: mm (inch)




Fig.3.2.1

3.2.1.2 Space dimension for dual-module unit

Unit: mm (inch)




Fig.3.2.2

## 3.2.1.3 Space dimension for three-module unit

Unit: mm (inch)




Fig.3.2.3

### 3.2.2 Space requirement for the top of outdoor unit

When there is wall (or similar obstruction) above the unit, keep the distance between the unit top and the wall at least 3000mm (118-1/8inch) or above. When the unit is located in a totally open space with no obstructions in four directions, keep the distance between the unit top and wall at least 1500mm (59inch) or above (See Fig.3.2.4). When space is limited within 1500mm (59inch) or the unit is not set in an open space, air outlet pipe is required to be installed in order to keep good ventilation (See Fig.3.2.5).




Fig.3.2.4

When the distance is less than 1500mm(59inch), connect on air duct so as to keep good ventilation




Fig.3.2.5

### 3.2.3 Space dimension for multiple-module unit

For keeping good ventilation, make sure there is no obstruction above the unit.

When the unit is located at a half-open space (front and left/right side is open), install the unit as per the same or opposite direction.

Unit: mm (inch)




Fig.3.2.6




Fig.3.2.7

3.2.4 Take seasonal wind into consideration when installing the outdoor unit

(1) Anti-monsoon installation requirements for unit not connecting exhaust duct:




Fig.3.2.8




Fig.3.2.9

(2) Anti-monsoon installation requirements for unit connecting exhaust duct:





Fig.3.2.10

3.2.5 Take snow into consideration when installing the outdoor unit



The height of the base should be higher than that of the snowfall

Fig.3.2.11



## 4.2 Physical Dimension of the Outdoor Unit and Mounting Hole

Outline and Physical Dimension of GMV-Q72WM/B-U(U), GMV-Q96WM/B-U(U) and GMV-Q120WM/B-U(U) unit.

Unit: mm (inch)




Fig.4.2.1



### 4.3 Connection Pipe

#### 4.3.1 Schematic Diagram of Piping Connection




Fig.4.3.1

#### 4.3.2 Schematic Diagram of Piping Sequence

GMV-Q72WM/B-U(U) , GMV-Q96WM/B-U(U) and GMV-Q120WM/B-U(U)




Fig.4.3.2

### 4.3.3 Allowable pipe length and drop height among indoor and outdoor units

Y type branch joint is adopted to connect indoor and outdoor units. Connecting method is shown in the figure below.

Remark: Equivalent length of one Y-type manifold is about 0.5m(1-3/4ft.).




Fig.4.3.3

H: Height difference between indoor unit and outdoor unit;

L12: Length from the first branch to the farthest IDU;

L11: Length from the first branch to the nearest IDU;

Equivalent length of one Y-type manifold pipe is 0.5m (1-3/4ft.).

Equivalent length of mode exchanger depends on the using situation, for example, when using one branch, the length is 1m (39-3/8inch), when using N branches, the length is N meters.

| R410A Refrigerant System  |                       | Allowable Value<br>m(ft.) | Fitting Pipe                                  |
|---|-----------------------|---------------------------|---|
| Total length (actual length) of fitting pipe  |                       | $\leq 1000(3280-3/4)$     | $L1+L2+L3+L4+\dots+L10+A11+A12+\dots+D21+D22$ |
| Length of farthest fitting pipe m(ft.)  | Actual length         | $\leq 165(541-1/4)$       | L   |
|   | Equivalent length     | $\leq 190(623-1/4)$       | —   |
| Difference between the pipe length from the first branch of IDU to the farthest IDU and the pipe length from the first branch of IDU to the nearest IDU |                       | $\leq 40(131-1/4)$        | $L12-L11$                                     |
| Equivalent length from the first branch to the furthest piping <sup>①</sup>   |                       | $\leq 40(131-1/4)$        | $L7+L8+L10+D22$                               |
| Height difference between outdoor unit and indoor unit  | Outdoor unit at upper | $\leq 90(295-1/4)$        | —   |
|   | Outdoor unit at lower | $\leq 90(295-1/4)$        | —   |
| Height difference between indoor units  |                       | $\leq 30(98-2/4)$         | $h1$  |
| Maximum length of Main pipe <sup>②</sup>  |                       | $< 90(295-1/4)$           | $L1$  |
| From IDU to its nearest branch <sup>③</sup>   |                       | $\leq 40(131-1/4)$        | A11,A12,B21,B22,D21,D22                       |

#### NOTICE!

① Normally, the pipe length from the first branch of IDU to the farthest IDU is 40m (131-1/4ft.).

Under the following conditions, the length can reach 90m (295-1/4ft.).

a) Actual length of pipe in total:

$$L1+L2x2+L3x2+L4x2+\dots+L10x2+A11+A12+\dots+D21+D22\leq 1000\text{m (3280-3/4ft.)}$$

b) Length between each IDU and its nearest branch A11, A12, B21, B22, D21, D22 $\leq$ 40m (131-1/4ft.).

c) Difference between the pipe length from the first branch of IDU to the farthest IDU and the pipe length from the first branch of IDU to the nearest IDU:  $L12-L11\leq 40\text{m (131-1/4ft.)}$ .

② When the maximum length of the main pipe from ODU to the first branch of IDU is  $\geq 90\text{m (295-1/4ft.)}$ , then adjust the pipe size of the gas pipe and liquid pipe of main pipe according to the following table.

| Outdoor Model     | Size of connection between outdoor unit and the first indoor branch |                              |                                    |
|-------------------|---|------------------------------|------------------------------------|
|                   | Low pressure gas pipe<br>mm(inch)                                   | Liquid pipe<br>mm(inch)      | High pressure gas pipe<br>mm(inch) |
| GMV-Q72WM/B-U(U)  | No need to enlarge pipe size  | No need to enlarge pipe size | No need to enlarge pipe size       |
| GMV-Q96WM/B-U(U)  | No need to enlarge pipe size  | $\Phi 12.7(1/2)$             | $\Phi 22.2(7/8)$                   |
| GMV-Q120WM/B-U(U) | No need to enlarge pipe size  | $\Phi 15.9(5/8)$             | $\Phi 28.6(1-1/8)$                 |
| GMV-Q144WM/B-U(U) | $\Phi 34.9(1-3/8)$  | $\Phi 15.9(5/8)$             | $\Phi 28.6(1-1/8)$                 |
| GMV-Q168WM/B-U(U) | $\Phi 34.9(1-3/8)$  | $\Phi 19.05(3/4)$            | $\Phi 28.6(1-1/8)$                 |
| GMV-Q192WM/B-U(U) | $\Phi 34.9(1-3/8)$  | $\Phi 19.05(3/4)$            | No need to enlarge pipe size       |
| GMV-Q216WM/B-U(U) | $\Phi 34.9(1-3/8)$  | $\Phi 19.05(3/4)$            | No need to enlarge pipe size       |
| GMV-Q240WM/B-U(U) | No need to enlarge pipe size  | $\Phi 19.05(3/4)$            | $\Phi 34.9(1-3/8)$                 |
| GMV-Q264WM/B-U(U) | No need to enlarge pipe size  | $\Phi 22.2(7/8)$             | $\Phi 34.9(1-3/8)$                 |
| GMV-Q288WM/B-U(U) | No need to enlarge pipe size  | $\Phi 22.2(7/8)$             | $\Phi 34.9(1-3/8)$                 |
| GMV-Q312WM/B-U(U) | No need to enlarge pipe size  | $\Phi 22.2(7/8)$             | $\Phi 34.9(1-3/8)$                 |
| GMV-Q336WM/B-U(U) | No need to enlarge pipe size  | $\Phi 22.2(7/8)$             | $\Phi 34.9(1-3/8)$                 |
| GMV-Q360WM/B-U(U) | No need to enlarge pipe size  | $\Phi 22.2(7/8)$             | No need to enlarge pipe size       |

③ If the length between an IDU and its nearest branch is above 10m (32-7/8ft.), then increase the size of the liquid pipe of IDU (only for the pipe size that is  $\leq 6.35\text{mm (1/4inch)}$ ).

## 4.3.4 Pipe connection of outdoor modules




Fig.4.3.4

Unit: m (ft.)




Fig.4.3.5

**NOTICE!** When the distance between outdoor units exceeds 2m (6-1/2ft.), U-type oil trap should be added at low pressure gas pipe.  $A+c \leq 10m$  (32-7/8ft.);  $b+c \leq 10m$  (32-7/8ft.);  $d \leq 10m$  (32-7/8ft.).

4.3.5 Size requirement for branch pipe and piping (main pipe)

4.3.5.1 Connection sketch map of single-module system




Fig.4.3.6

Connection sketch map of multi-module system




Fig.4.3.7

4.3.5.2 For single unit system, select appropriate pipe between outdoor unit and the first indoor branch (“L”) as per the pipe size of outdoor unit. Pipe size of basic outdoor module is shown as follows:

Between outdoor unit and the first indoor branch

| Basic module      | Pipe between outdoor unit and the first indoor branch |                      |                                 |
|-------------------|---|----------------------|---------------------------------|
|                   | Low pressure gas pipe mm(inch)                        | Liquid pipe mm(inch) | High pressure gas pipe mm(inch) |
| GMV-Q72WM/B-U(U)  | Φ19.05(3/4)   | Φ9.52(3/8)           | Φ15.9(5/8)                      |
| GMV-Q96WM/B-U(U)  | Φ22.2(7/8)  | Φ9.52(3/8)           | Φ19.05(3/4)                     |
| GMV-Q120WM/B-U(U) | Φ28.6(1-1/8)  | Φ12.7(1/2)           | Φ22.2(7/8)                      |

4.3.5.3 For multi-module system, select appropriate branch (“M1 / M2 / M3”) connected to outdoor module as per the pipe size of basic outdoor module. Pipe size of basic outdoor module is shown as follows:

Pipe between module and outdoor branch “M1 / M2 / M3”

| Basic module      | Size of the pipe between module and outdoor branch |                      |                                 |
|-------------------|--|----------------------|---------------------------------|
|                   | Low pressure gas pipe mm(inch)                     | Liquid pipe mm(inch) | High pressure gas pipe mm(inch) |
| GMV-Q72WM/B-U(U)  | Φ19.05(3/4)  | Φ9.52(3/8)           | Φ15.9(5/8)                      |
| GMV-Q96WM/B-U(U)  | Φ22.2(7/8)   | Φ9.52(3/8)           | Φ19.05(3/4)                     |
| GMV-Q120WM/B-U(U) | Φ28.6(1-1/8)                                       | Φ12.7(1/2)           | Φ22.2(7/8)                      |

Selection of branch “Y1 / Y2” of outdoor modules

|  | Module's capacity C (Btu/h) | Model |
|--|-----------------------------|-------|
| Selection of branch of outdoor modules | $X \leq 327500$             | ML01R |
|  | $327500 < X$                | ML02R |

4.3.5.4 Size of connection pipe “M4” between branches of each basic module

Size of connection pipe between branches of each basic module is determined by the total rated capacity of upstream modules.

Connection pipe “M4” between branches of outdoor module

| Total rated capacity of upstream modules: Q (Btu/h) | Size of connection pipe between branches of outdoor module |                      |                                 |
|---|--|----------------------|---------------------------------|
|   | Low pressure gas pipe mm(inch)                             | Liquid pipe mm(inch) | High pressure gas pipe mm(inch) |
| $Q \leq 72000$                                      | Φ19.05(3/4)  | Φ9.52(3/8)           | Φ15.9(5/8)                      |
| $72000 < Q \leq 96000$                              | Φ22.2(7/8)   | Φ9.52(3/8)           | Φ19.05(3/4)                     |
| $96000 < Q \leq 120000$                             | Φ28.6(1-1/8)   | Φ12.7(1/2)           | Φ22.2(7/8)                      |
| $120000 < Q \leq 144000$                            | Φ28.6(1-1/8)   | Φ12.7(1/2)           | Φ22.2(7/8)                      |
| $144000 < Q \leq 168000$                            | Φ28.6(1-1/8)   | Φ15.9(5/8)           | Φ22.2(7/8)                      |
| $168000 < Q \leq 216000$                            | Φ28.6(1-1/8)   | Φ15.9(5/8)           | Φ28.6(1-1/8)                    |
| $216000 < Q \leq 240000$                            | Φ34.9(1-3/8)   | Φ15.9(5/8)           | Φ28.6(1-1/8)                    |
| $240000 < Q \leq 312000$                            | Φ34.9(1-3/8)   | Φ19.05(3/4)          | Φ28.6(1-1/8)                    |
| $312000 < Q \leq 336000$                            | Φ34.9(1-3/8)   | Φ19.05(3/4)          | Φ28.6(1-1/8)                    |
| $336000 < Q \leq 360000$                            | Φ41.3(1-5/8)   | Φ19.05(3/4)          | Φ34.9(1-3/8)                    |

#### 4.3.5.5 Size of connection pipe “L” between the terminal outdoor branch and the first indoor branch

Connection pipe “L” between outdoor unit and the first indoor branch

| Module            | Size of connection between outdoor unit and the first indoor branch |                  |                             |
|-------------------|---|------------------|-----------------------------|
|                   | Low pressure gas pipe (mm)  | Liquid pipe (mm) | High pressure gas pipe (mm) |
| GMV-Q72WM/B-U(U)  | Φ19.05(3/4)   | Φ9.52(3/8)       | Φ15.9(5/8)                  |
| GMV-Q96WM/B-U(U)  | Φ22.2(7/8)  | Φ9.52(3/8)       | Φ19.05(3/4)                 |
| GMV-Q120WM/B-U(U) | Φ28.6(1-1/8)  | Φ12.7(1/2)       | Φ22.2(7/8)                  |
| GMV-Q144WM/B-U(U) | Φ28.6(1-1/8)  | Φ12.7(1/2)       | Φ22.2(7/8)                  |
| GMV-Q168WM/B-U(U) | Φ28.6(1-1/8)  | Φ15.9(5/8)       | Φ22.2(7/8)                  |
| GMV-Q192WM/B-U(U) | Φ28.6(1-1/8)  | Φ15.9(5/8)       | Φ28.6(1-1/8)                |
| GMV-Q216WM/B-U(U) | Φ28.6(1-1/8)  | Φ15.9(5/8)       | Φ28.6(1-1/8)                |
| GMV-Q240WM/B-U(U) | Φ34.9(1-3/8)  | Φ15.9(5/8)       | Φ28.6(1-1/8)                |
| GMV-Q264WM/B-U(U) | Φ34.9(1-3/8)  | Φ19.05(3/4)      | Φ28.6(1-1/8)                |
| GMV-Q288WM/B-U(U) | Φ34.9(1-3/8)  | Φ19.05(3/4)      | Φ28.6(1-1/8)                |
| GMV-Q312WM/B-U(U) | Φ34.9(1-3/8)  | Φ19.05(3/4)      | Φ28.6(1-1/8)                |
| GMV-Q336WM/B-U(U) | Φ34.9(1-3/8)  | Φ19.05(3/4)      | Φ28.6(1-1/8)                |
| GMV-Q360WM/B-U(U) | Φ41.3(1-5/8)  | Φ19.05(3/4)      | Φ34.9(1-3/8)                |

#### 4.3.5.6 Branch selection of mode exchanger (“A1, A2”)

Select branch of mode exchanger as per total capacity of downstream indoor unit(s). Please refer to the following table.

Model selection for branch “A1 / A2” of mode exchanger:

| R410A refrigerant system | Total Capacity of the Downstream Indoor Unit X(Btu/h) | Model    |
|--------------------------|---|----------|
| Y-Type Branch Pipe       | $X \leq 17100$  | FQ01Na/A |
|                          | $17100 < X \leq 72000$                                | FQ02Na/A |
|                          | $72000 < X \leq 96000$                                | FQ03Na/A |
|                          | $96000 < X \leq 232000$                               | FQ04Na/A |
|                          | $232000 < X \leq 327500$                              | FQ05Na/A |
|                          | $327500 < X$  | FQ06Na/A |

#### 4.3.5.7 Piping size among upstream branches of mode exchanger (“n1/n2/n3/n4”)

| Total rated capacity of downstream indoor units: C(Btu/h) | Size of connection pipe between branches of mode exchanger |                      |                                 |
|---|--|----------------------|---------------------------------|
|   | Low pressure gas pipe mm(inch)                             | Liquid pipe mm(inch) | High pressure gas pipe mm(inch) |
| $C \leq 17100$  | Φ12.7(1/2)   | Φ6.35(1/4)           | Φ12.7(1/2)                      |
| $17100 < C \leq 48500$                                    | Φ15.9(5/8)   | Φ9.52(3/8)           | Φ12.7(1/2)                      |
| $48500 < C \leq 72000$                                    | Φ19.05(3/4)  | Φ9.52(3/8)           | Φ15.9(5/8)                      |
| $72000 < C \leq 96000$                                    | Φ22.2(7/8)   | Φ9.52(3/8)           | Φ19.05(3/4)                     |
| $96000 < C \leq 120000$                                   | Φ28.6(1-1/8)   | Φ12.7(1/2)           | Φ22.2(7/8)                      |

| Total rated capacity of downstream indoor units: C(Btu/h) | Size of connection pipe between branches of mode exchanger |                      |                                 |
|---|--|----------------------|---------------------------------|
|   | Low pressure gas pipe mm(inch)                             | Liquid pipe mm(inch) | High pressure gas pipe mm(inch) |
| 120000<C≤144000   | Φ28.6(1-1/8)   | Φ12.7(1/2)           | Φ22.2(7/8)                      |
| 144000<C≤168000   | Φ28.6(1-1/8)   | Φ15.9(5/8)           | Φ22.2(7/8)                      |
| 168000<C≤216000   | Φ28.6(1-1/8)   | Φ15.9(5/8)           | Φ28.6(1-1/8)                    |
| 216000<C≤240000   | Φ34.9(1-3/8)   | Φ15.9(5/8)           | Φ28.6(1-1/8)                    |
| 240000<C≤312000   | Φ34.9(1-3/8)   | Φ19.05(3/4)          | Φ28.6(1-1/8)                    |
| 312000<C≤336000   | Φ34.9(1-3/8)   | Φ19.05(3/4)          | Φ28.6(1-1/8)                    |
| 336000<C≤360000   | Φ41.3(1-5/8)   | Φ19.05(3/4)          | Φ34.9(1-3/8)                    |

#### 4.3.5.8 Piping size among downstream branches of mode exchanger “a / h”

| Rated capacity of indoor unit C(Btu/h) | Size of piping among downstream branches of mode exchanger |                      |
|--|--|----------------------|
|  | Gas Pipe mm(inch)  | Liquid Pipe mm(inch) |
| C≤9500                                 | Φ9.52(3/8)   | Φ6.35(1/4)           |
| 9500<C≤17100                           | Φ12.7(1/2)   | Φ6.35(1/4)           |
| 17100<C≤48500                          | Φ15.9(5/8)   | Φ9.52(3/8)           |

#### 4.3.5.9 Branch selection of downstream indoor unit of mode exchanger (“B1/B2/B3”)

| R410A refrigerant system | Total rated capacity of downstream indoor units: X(Btu/h) | Model   |
|--------------------------|---|---------|
| Y-type branch            | X≤48500   | FQ01A/A |

#### 4.3.5.10 Piping size between mode exchanger and downstream indoor unit (“b / c / d / g”)

| Rated capacity of indoor unit C(Btu/h) | Pipe between mode exchanger and IDU |                      |
|--|-------------------------------------|----------------------|
|  | Gas Pipe mm(inch)                   | Liquid Pipe mm(inch) |
| C≤9500                                 | Φ9.52(3/8)                          | Φ6.35(1/4)           |
| 9500<C≤17100                           | Φ12.7(1/2)                          | Φ6.35(1/4)           |
| 17100<C≤48500                          | Φ15.9(5/8)                          | Φ9.52(3/8)           |

#### 4.3.5.11 Piping between indoor branch and indoor unit (“e / f / i / j / k”)

Size of connection pipe between indoor branch and indoor unit should be consistent with the connection pipe of indoor unit.

Piping between indoor branch and indoor unit “e / f / i / j / k”.

| Rated capacity of indoor units: C (Btu/h) | Size of connection pipe between indoor branch and indoor unit |                      |
|---|---|----------------------|
|   | Gas pipe mm(inch)   | Liquid pipe mm(inch) |
| C≤9500                                    | Φ9.52(3/8)  | Φ6.35(1/4)           |
| 9500<C≤17100                              | Φ12.7(1/2)  | Φ6.35(1/4)           |
| 17100<C≤48500                             | Φ15.9(5/8)  | Φ9.52(3/8)           |




4.3.5.12 Piping between indoor branches (“I”)

| Rated capacity of the downstream indoor units C(kW) | Size of connection pipe between indoor branches |                  |
|---|---|------------------|
|   | Gas pipe (mm)                                   | Liquid pipe (mm) |
| C≤9500  | Φ9.52(3/8)                                      | Φ6.35(1/4)       |
| 9500<C≤17100  | Φ12.7(1/2)                                      | Φ6.35(1/4)       |
| 17100<C≤48500                                       | Φ15.9(5/8)                                      | Φ9.52(3/8)       |

4.3.6 Connection method when capacity of indoor unit exceeds 48500Btu/h

When connecting to the indoor unit with capacity of over 48500Btu/h, it is not allowed to connect with only one branch; it must use two branches controlled by the same mainboard for parallel connection.

| Parallel connection       | Indoor unit Communication connection for mode exchanger | Remarks  |
|---------------------------|---|--|
| Indoor unit No.1 and No.2 | “1D1 1D2”   | Parallel connection can be conducted only as the combination of this table, it is not allowed to otherwise connect. Note that after the connection, manually set the SA2 dial code of corresponding mainboard, and dial the code in the first place to number end. |
| Indoor unit No.3 and No.4 | “3D1 3D2”   |  |
| Indoor unit No.5 and No.6 | “5D1 5D2”   |  |
| Indoor unit No.7 and No.8 | “7D1 7D2”   |  |



Connecting method is as shown in the Fig.4.3.8




Fig.4.3.8

#### 4.3.6.1 Branch selection of indoor unit of mode exchanger (“C1”)

| R410A refrigerant system | Capacity of downstream indoor units: X (Btu/h) | Model   |
|--------------------------|--|---------|
| Y-type branch            | $48500 < X \leq 96000$                         | FQ01B/A |

#### 4.3.6.2 Piping size between mode exchanger and downstream indoor unit (“m”)

Size of connection pipe between indoor branch and indoor unit should be consistent with the connection pipe of indoor unit.

Piping between indoor branch and indoor unit “m”.

| Rated capacity of indoor units:<br>C(Btu/h) | Size of connection pipe between indoor branch and indoor unit |                      |
|---|---|----------------------|
|   | Gas pipe mm(inch)   | Liquid pipe mm(inch) |
| $48500 < C \leq 72000$                      | $\Phi 19.05(3/4)$   | $\Phi 9.52(3/8)$     |
| $72000 < C \leq 96000$                      | $\Phi 22.2(7/8)$  | $\Phi 9.52(3/8)$     |

### 4.4 Installation of the Connection Pipe

#### 4.4.1 Precautions when installing the connection pipe

##### NOTICE!

Before welding the pipeline sealing cap, please make sure there's no refrigerant in pipeline. If welding it directly, it may cause unnecessary property damage or personal injury.

- (1) Conform to the following principles during piping connection: Connection pipeline should be as short as possible. The height difference between indoor and outdoor units should be as short as possible. Keep number of bends as little as possible. The radius of curvature should be as large as possible.
- (2) Weld the connection pipes between indoor and outdoor unit. Please strictly conform to the requirements for welding process. Rosin joints and pin holes are not allowable.
- (3) When laying the pipes, be careful not to deform them. The radius of bending parts should be more than 200mm (7-7/8inch). The pipes cannot be repeatedly bent or stretched, otherwise the material will get harden. Do not bend or stretch the pipe over three times at the same position.
- (4) Please use a torque wrench to connect union nut on the indoor unit. See Fig.4.4.1.




Fig.4.4.1

- 1) Align the expansion end of copper pipe with the center of threaded joint. Tighten the flare nuts with your hands.

- 2) Tighten the flare nuts with torque wrench until you hear “click” sound.
- 3) Use sponge to wrap the connecting pipe and joints without thermal insulation and tie it up with plastic tape.
- 4) A mounting support for the connection pipe is required.
- 5) The curvature degree of connection pipe should not be small, otherwise the pipe might crack. Installation personnel should use tube bender when bending the pipe.
- 6) Don't forcibly stretch the pipe joint, otherwise indoor capillary or other pipes might be damaged and lead to refrigerant leakage.

#### 4.4.2 Installation of the manifold

The main function of manifold is used to shunt the refrigerant. Pay attention to the following points when installing it:

- (1) When installing the manifold, it should be as close as possible to the indoor unit to reduce the influence of the indoor unit manifold on the refrigerant distribution.
- (2) The manifold must be matched with the equipment. The other products which are not specified by the manufacturer shall not be used.
- (3) Check the model before installing the manifold. Do not use it incorrectly.

1) Y-type manifold is as follows. Y-type manifold can be installed vertically or horizontally.




Fig.4.4.2

- 2) The installation of the branch pipe has the following requirements. Please install it according to the angle shown in the Fig.4.4.3. Improper installation may lead to malfunction of the outdoor unit.





Fig.4.4.3

- 3) Manifold has several pipe sections with different pipe size, which facilitates to match with various copper pipe. Use pipe cutter to cut in the middle of the pipe section with different pipe size. See the Fig.4.4.4.




Fig.4.4.4

- 4) The length of a straight pipe between two manifolds cannot be less than 500 mm.
- 5) The length of a straight pipe before the main pipe port of the manifold cannot be less than 500 mm.
- 6) The length of a straight pipe between the branch of the manifold and the IDU cannot be less than 500 mm.

Unit: mm(inch)




Fig.4.4.5

### 4.4.3 Fixation of Manifold

- (1) There must be three fixing point for both horizontal and vertical installation of the Y-type manifold.

Fixing point 1: 100 mm on the main inlet manifold from the welding point.

Fixing point 2: 200 mm on the main branched pipe from the welding point.

Fixing point 3: 250 mm on the branched pipe from the welding point.




Fig.4.4.6

- (2) The branches of the manifold should be parallel and should not be overlapped.
- (3) The liquid pipe and the gas pipe should have the same pipe length and the same laying circuit.
- (4) Since the structure of the manifold is relatively complicated, it must be rigorous and careful for heat preservation to ensure the tight insulation.
- (5) Thermal insulation for pipeline.

- 1) To avoid condensate or water leakage on connecting pipe, the gas pipe and liquid pipe must be wrapped with thermal insulating material and adhesive pipe for insulation from the air.

- 2) For heat pump unit, liquid pipe should bear 70°C(158°F) or above, and gas pipe should bear 120°C(248°F) or above. For cooling only unit, both liquid pipe and gas pipe should bear 70°C(158°F) or above. Example: Polyethylene foam can bear 120°C(248°F) above and foaming polyethylene can bear 100 °C (212°F) above.

- 3) Joints at indoor and outdoor units should be wrapped with insulating material and leave no clearance between pipe and wall. See Fig.4.4.7.




Fig.4.4.7

- 4) Manifold attached foam cannot be taken as insulating material.

- 5) When wrapping the tape, the later circle should cover half of the former one. Don't wrap

the tape so tightly, otherwise the insulation effect will be weakened.

- 6) After wrapping the pipe, adopt sealing material to completely fill the hole so as to prevent wind and rain from entering the room.

#### 4.4.4 Support and protection for pipeline

- (1) Support should be made for hanging connection pipe. Distance between each support can not be over 1m (39-3/8inch).
- (2) Protection towards accidental damage should be made for outdoor pipeline. When the pipeline exceeds 1m (39-3/8inch), a pin. Board should be added for protection.

### 4.5 Air Purging and Refrigerant Charge

#### 4.5.1 Air purging

- (1) Confirm outdoor liquid and gas valves are closed. Air purging from the nozzle located on liquid and gas valves by vacuum pump. See Fig.4.5.1.
- (2) When there are more than 2 outdoor units, air purging from the nozzle located on the oil balance valve. Confirm outdoor oil balance valves are closed. See Fig.4.5.2.




Fig.4.5.1




Fig.4.5.2

### 4.5.2 Additional refrigerant charging

Outdoor unit has been charged refrigerant before delivery.

Charge additional refrigerant for field-installed connecting pipe. If the pipeline is longer than 1m (39-3/8inch), please refer to the following table for charging amount of refrigerant. (Liquid pipe prevails)

How much additional refrigerant should be charged?

Total refrigerant charging amount R= Pipeline charging amount A + Refrigerant charging amount B of every module

(1) Pipeline charging amount

Added refrigerant quantity A for piping =  $\sum$ Liquid pipe length  $\times$  Added refrigerant quantity for each meter (inch) of liquid pipe.

|         | Diameter of liquid pipe (mm(inch)) |         |           |            |           |           |           |           |
|---------|------------------------------------|---------|-----------|------------|-----------|-----------|-----------|-----------|
|         | 28.6(1-1/8)                        | 25.4(1) | 22.2(7/8) | 19.05(3/4) | 15.9(5/8) | 12.7(1/2) | 9.52(3/8) | 6.35(1/4) |
| kg/m    | 0.680                              | 0.520   | 0.350     | 0.250      | 0.170     | 0.110     | 0.054     | 0.022     |
| OZ/inch | 0.61                               | 0.47    | 0.31      | 0.22       | 0.15      | 0.10      | 0.05      | 0.02      |

(2) Refrigerant charging amount B of every module

| Refrigerant charging amount B of every module<br>kg(Pounds) |                                 | Rated Capacity(kBtu/h) |          |           |
|---|---------------------------------|------------------------|----------|-----------|
| IDU/ODU rated capacity<br>collocation ratio C               | Quantity of included<br>IDUs(N) | 72                     | 96       | 120       |
| 50% $\leq$ C $\leq$ 90%                                     | N<4                             | 0                      | 0        | 0         |
|   | N $\geq$ 4                      | 0.5(1.1)               | 0.5(1.1) | 0.5(1.1)  |
| 90%<C $\leq$ 105%   | N<4                             | 1(2.2)                 | 1(2.2)   | 1.5(3.3)  |
|   | 8>N $\geq$ 4                    | 3.5(7.7)               | 2(4.4)   | 3(6.6)    |
|   | N $\geq$ 8                      | 4(8.8)                 | 3.5(7.7) | 5.5(12.1) |
| 105%<C $\leq$ 135%  | N<4                             | 2(4.4)                 | 2(4.4)   | 2.5(5.5)  |
|   | 8>N $\geq$ 4                    | 4(8.8)                 | 3.5(7.7) | 4(8.8)    |
|   | N $\geq$ 8                      | 4.5(9.9)               | 4.5(9.9) | 5(11.0)   |

#### **NOTICE!**

(1) IDU/ODU rated capacity collocation ratio C = Sum of rated cooling capacity of indoor unit / Sum of rated cooling capacity of outdoor unit.

(2) If all of the indoor units are fresh air indoor units, the quantity of refrigerant added to each module is 0kg.

(3) If fresh air indoor units is connected with normal VRF indoor unit, adopt the perfusion method for normal indoor unit for perfusion.

For example 1:

The ODU is composed of the module: 120 kBtu/h.

The IDUs are made up of 4 sets of 30 kBtu/h.

IDU/ODU rated capacity collocation ratio C= 30 $\times$ 4/(120)=100%.The quantity of included IDUs is more than 4 sets. Please refer to the above table.

Refrigerant charging amount B for 120 kBtu/h module is 3.0kg (6.6pounds).

So, Refrigerant charging amount B =3kg (6.6pounds).

Suppose the Pipeline charging amount  $A = \Sigma$  Liquid pipe length  $\times$  refrigerant charging amount of every 1m (39-3/8inch) liquid pipe=2kg (4.4 pounds)

Total refrigerant charging amount  $R = 2 + 3 = 5\text{kg}$  (4.4+6.6=11pounds).

For example 2:

Outdoor unit is a 72kBtu/h module and the indoor unit is a 72kBtu/h fresh air unit. The quantity (B) of refrigerant added to this module is 0kg (0pounds).

So, Refrigerant charging amount  $B = 0\text{kg}$  (0pounds).

Suppose the Pipeline charging amount  $A = \Sigma$ Length of liquid pipe  $\times$  Quantity of refrigerant added to liquid pipe per meter) = 5kg (11pounds).

Total refrigerant charging amount  $R = 5 + 0 = 5\text{kg}$  (11+0=11pounds).

After confirming that there is no leakage from the system, when the compressor is not in operation, charge additional R410A with specified amount to the unit through the filling opening of the liquid pipe valve of the outdoor unit. If required additional refrigerant cannot be quickly filled for increase of pressure in the pipe, set the unit at cooling startup and then fill the refrigerant from gas valve of outdoor unit. If ambient temperature is low, the unit can't be set to cooling mode but heating mode.

#### 4.5.3 Precautions on Refrigerant Leakage

- (1) Personnel related to air conditioning engineering design and installation operators must abide by the safety requirement for preventing refrigerant leakage specified in local laws and regulations.
- (2) The units adopt the R410A refrigerant, which is nonflammable and nontoxic. However, the space for refrigerant leakage must be sufficient to ensure that the refrigerant concentration does not exceed that specified in the safety requirement; otherwise, people involved can be stifled by the refrigerant. For example the maximum allowed concentration level of refrigerant to a humanly space for R410A according to the appropriate European Standard is limited to  $0.44 \text{ kg/m}^3$ .


The maximum amount of refrigerant (kg) in the system = The volume of the room ( $\text{m}^3$ )  $\times$  The maximum allowed concentration level of refrigerant ( $\text{kg/m}^3$ )

Total amount of refrigerant (kg) in the system = Total additional charging amount (kg) + Amount of refrigerant (kg) which is charged before leaving the factory (for the system consisting of multiple modules in parallel, the accumulative charge quantity of modules before leaving the factory is used)

Total amount of refrigerant (kg) in the system  $\leq$  The maximum amount of refrigerant (kg) in the system

- (3) When the total amount of refrigerant in the system is more than the maximum amount of refrigerant, the cooling system should be designed again. In this case, the cooling system can also be separated into several cooling systems with small capacity, or add corresponding ventilation measures or alarming display.





- ❶ Flow direction of refrigerant leakage
- ❷ Room for refrigerant leakage.

Fig.4.5.3

Since the concentration of refrigerant is greater than that of air, pay attention to the spaces where the refrigerant may residue, for example, the basement.

## 4.6 Electric Wiring

### 4.6.1 Wiring precautions

| <b>⚠ WARNING</b>  |
|---|
| (1) Wiring should conform to national rules. All the parts, materials, electric work should be in accordance with local codes.  |
| (2) Rated voltage and exclusive power supply should be used.  |
| (3) Power cord should be fixed soundly and reliable. Never forcibly pull the power cord.  |
| (4) Wire size of power cord should be large enough. The damaged power cord and connecting wire should be replaced by exclusive cable.   |
| (5) All the electrical work should be performed by professional personnel as per local law, regulation and this manual.   |
| (6) Connect the unit to the special earthing device and make sure the unit is earthed soundly.  |
| (7) Air switch and circuit breaker is required to be set. Air switch should have both magnetic trip and thermal trip functions so as to protect the unit when short-circuit and overload happens. D-type breaker is advised to be used. |
| (8) Wiring diagram attached on the unit is prevailed.   |

## 4.6.2 Wiring of power cord

Every unit should have corresponding short-circuit and overload protection. And also a main switch is required to control power supply or disconnection. See Fig.4.6.1.




Fig.4.6.1

Refer to the following table for outdoor unit power cord specifications and circuit breakers.

| Outdoor units     | Power Supply | Fuse Capacity | Minimum Circuit Ampacity | Maximum Overcurrent Protection |
|-------------------|--------------|---------------|--------------------------|--------------------------------|
|                   | V/ Ph /Hz    | A             | A                        | A                              |
| GMV-Q72WM/B-U(U)  | 460V 3~ 60Hz | 20            | 15                       | 20                             |
| GMV-Q96WM/B-U(U)  | 460V 3~ 60Hz | 25            | 18                       | 25                             |
| GMV-Q120WM/B-U(U) | 460V 3~ 60Hz | 30            | 25                       | 30                             |
| GMV-Q144WM/B-U(U) | 460V 3~ 60Hz | 20+20         | 15+15                    | 20+20                          |
| GMV-Q168WM/B-U(U) | 460V 3~ 60Hz | 20+25         | 15+18                    | 20+25                          |
| GMV-Q192WM/B-U(U) | 460V 3~ 60Hz | 25+25         | 18+18                    | 25+25                          |
| GMV-Q216WM/B-U(U) | 460V 3~ 60Hz | 25+30         | 18+25                    | 25+30                          |
| GMV-Q240WM/B-U(U) | 460V 3~ 60Hz | 30+30         | 25+25                    | 30+30                          |
| GMV-Q264WM/B-U(U) | 460V 3~ 60Hz | 20+25+25      | 15+18+18                 | 20+25+25                       |
| GMV-Q288WM/B-U(U) | 460V 3~ 60Hz | 25+25+25      | 18+18+18                 | 25+25+25                       |
| GMV-Q312WM/B-U(U) | 460V 3~ 60Hz | 25+25+30      | 18+18+25                 | 25+25+30                       |
| GMV-Q336WM/B-U(U) | 460V 3~ 60Hz | 25+30+30      | 18+25+25                 | 25+30+30                       |
| GMV-Q360WM/B-U(U) | 460V 3~ 60Hz | 30+30+30      | 25+25+25                 | 30+30+30                       |

| <b>⚠ WARNING</b>   |
|--|
| (1) Specification of circuit breaker and power cord is selected on the basis of unit's maximum power (max. current).   |
| (2) Specification of power cord is based on the working condition where ambient temperature is 40°C (104°F) and multi-core cable with copper conductor (working temperature is 90°C (194°F), e.g. power cable with YJV cross-linked copper, insulated PE and PVC sheath) is lying on the surface of slot. If working condition is different, please adjust the specification according to national standard. |
| (3) Copper-core cable must be used.  |
| (4) The above sectional area is suitable for a maximum distance of 15m (49-1/4ft.). If it's over 15m (49-1/4ft.), sectional area must be expanded to prevent overload current from burning the wire or causing fire hazard.  |
| (5) Specification of circuit breaker is based on the working condition where the ambient temperature of circuit breaker is 40°C (104°F). If working condition is different, please adjust the specification according to national standard.  |

#### 4.6.3 Connection of power cord

| <b>⚠ WARNING</b>   |
|--|
| (1) Before obtaining access to terminals, all supply circuits must be disconnected.  |
| (2) If units are type I electrical appliances, they must be reliably grounded.   |
| (3) Ground resistance must be in accord with requirements of local standard.   |
| (4) The green-yellow wire within units are ground wire. Do not use it for other purposes. Nor should it be cut off or secured by tapping screws. Otherwise, it may cause electric shock.   |
| (5) Power supply at user side must have reliable ground terminal. Do not connect ground wire to the following places: <ol style="list-style-type: none"> <li>1) Water pipe.</li> <li>2) Gas pipe.</li> <li>3) Drainage pipe.</li> <li>4) Other places that are considered by professionals as unreliable.</li> </ol> |
| (6) Power cord and communication wire should be separated, with a distance of more than 20cm (7-7/8inch). Otherwise, system's communication may not work well.   |

Steps graphic of power cord connection:

- (1) Knock off the cross-through opening that's used for leading the external power cord, with the cross-through rubber ring on the opening. Then lead the cable through the opening. Connect L1, L2, L3 of power cord and ground wire separately to the positions on wiring board (for power supply) that are marked with L1, L2, L3 and the ground screw nearby.
- (2) Fasten the power cord with cable tie.
- (3) Lay the power cable and communication cable for the ODU according to the marker of external connection circuit diagram.

## 4.7 System Communication

### 4.7.1 Communication system include

- (1) Communication among outdoor basic modules.
- (2) Communication between ODU and IDU.
- (3) Communication among IDUs.
- (4) Communication between IDU and wired controller.

- (5) Connection between IDU and light board receiver.
- (6) Communication between different refrigeration systems.

#### 4.7.2 Communication mode of GMV5 HR Modular DC Inverter Units

CAN bus mode is taken for communication between IDU and ODU and communication among IDUs.

#### 4.7.3 Selection and connection mode of GMV5 HR communication material

##### 4.7.3.1 Select communication material

**NOTICE!** If air conditioners are installed at places where there’s strong electromagnetic interference, the communication wire of IDU and wired controller must use shielded wire and the communication wire between IDU and IDU/ODU must use shielded twisted pair.

- (1) Select communication wire between IDU and wired controller

| Material type                                    | Total length of communication line between IDU unit and wired controller L m(ft.) | Wire size           | Remarks  |
|--|---|---------------------|--|
| Light/Ordinary polyvinyl chloride sheathed cord. | $L \leq 250(820-1/4)$   | 2×AWG18<br>~2×AWG16 | <ol style="list-style-type: none"> <li>Total length of communication line can't exceed 250m (820-1/4ft.).</li> <li>The cord shall be Circular cord (the cores shall be twisted together).</li> <li>If unit is installed in places with intense magnetic field or strong interference, it is necessary to use shielded wire.</li> </ol> |

Graphic of connection between IDU and wired controller




Fig.4.7.1

- (2) Select communication wire between ODU and IDU

| Material Type                                    | Total Length L(m(ft.)) of Communication Cable between IDU Unit and IDU(ODU) Unit | Wire size                    | Remarks   |
|--|--|------------------------------|---|
| Light/Ordinary polyvinyl chloride sheathed cord. | $L \leq 1000(3280-7/8)$  | $\geq 2 \times \text{AWG}18$ | <ol style="list-style-type: none"> <li>If the wire diameter is enlarged to 2 ×AWG16, the total communication length can reach 1500m (4921-1/4ft.).</li> <li>The cord shall be Circular cord (the cores shall be twisted together).</li> <li>If unit is installed in places with intense magnetic field or strong interference, it is necessary to use shielded wire.</li> </ol> |




Fig.4.7.2

**NOTICE!** All of the selected communication wire must be consistent with local laws and regulations.

#### 4.7.3.2 Connection mode of communication

(1) All communication wires of GMV5 HR must be connected in series rather than in star.




Fig.4.7.3




Fig.4.7.4




Fig.4.7.5




Fig.4.7.6

(2) All communication wires of GMV5 HR are connected by screws.




Fig.4.7.7

(3) If a single communication wire is not long enough and needs to be connected, the connected joint must be welded or pressure-welded. Do not simply twist the wires together.

#### 4.7.4 Communication address

Auto addressing technology is adopted for GMV5 HR IDU and ODU. No need to set address codes manually. Only the addresses of master unit and central control are needed to be set (address of central control is only needed when there are multiple refrigeration systems).

**NOTICE!** When installing remote monitor or central controller, displacement on indoor units' project codes must be made. Otherwise, there will be collision malfunction of the project codes. For detail operation methods, please refer to the Installation and Maintenance Manual.

## 4.8 Connection Method and Steps for System Communication

### 4.8.1 Communication connection between IDU and ODU

**NOTICE! The centralized controller can be installed when it is necessary.**

Connect IDU and ODU via terminal D1/D2 of communication wiring board. Below are the connection graphics of single unit and modular units:




Fig.4.8.1 Connection of communication for single-module system and multi-module converter system.






Fig.4.8.2 Connection of communication for multi-module system and multi-module converter system.

| <b>NOTICE!</b>   |
|--|
| (1) For modular outdoor units, if there are multiple outdoor modules, then the master unit must be the first outdoor module on the communication wire and should not connect with IDU (master unit is set by SA8 of the outdoor main board). |
| (2) For modular outdoor units, if there are multiple outdoor modules, then indoor units must be connected with the last slave module of ODU (slave module is set by SA8 of the outdoor main board).  |
| (3) Communication wire and power cord must be separated.   |
| (4) Communication wire must be of proper length. Extension is not allowed.   |
| (5) IDUs must be connected in series. The last IDU must be connected with the communication matched resistance (supplied in the list of ODU spare parts).  |

### 4.8.2 Communication connection between IDU and wired controller

There are 4 kinds of connection between IDU and wired controller, as shown below:




Fig.4.8.3 one wired controller controls one IDU




Fig.4.8.4 Two wired controller controls one IDU




Fig.4.8.5 one wired controller controls multiple IDUs




Fig.4.8.6 Two wired controllers control multiple IDUs

When two wired controllers control multiple IDUs, the wired controller can be connected to any one IDU, provided that the connected IDU is of the same series. Meanwhile, one and only one of the wired controllers must be set as a slave controller. At most 16 IDUs can be controlled by wired controllers and the connected IDUs shall be within a same IDU network.

No matter when unit is turned on or off, slave controller can be set.

How to set a slave controller: hold “function” button on the designated controller for 5s, and temperature zone displays C00. Continue holding “function” button for 5s and setting screen of controller parameter will come out. Default temperature zone displays P00.

Press ▲ button or ▼ button to select parameter code P13. Press “mode” button to switch to setup of parameter values. Then the parameter value will blink. Press ▲ button or ▼ button to select code 02. And then press “confirm/cancel” to finish setting.

Press “confirm/cancel” to return to the previous display until you exit from the setup of parameter values.

Below are user’s parameter settings:

| Parameter code | Parameter name                      | Parameter scope   | Default value | Remark   |
|----------------|-------------------------------------|---|---------------|--|
| P13            | Set up address for wired controller | 01: master wired controller<br>02: slave wired controller | 01            | When 2 wired controllers control one or more IDUs, they shall have different addresses. Slave wired controller (02) can’t set up units’ parameters except its own address. |

#### 4.8.3 Communication connection of central controlling units

**NOTICE!** The centralized controller can be installed when it is necessary.

Port connection G1 and G2 on the communication wiring board of master unit among each VRF system (see below)





Fig.4.8.7

## 4.9 External Electrical Wiring Diagram

### **⚠ WARNING**

- (1) Every unit should be equipped with a circuit breaker for short-circuit and overload protection. In general, circuit breaker is at OFF status.
- (2) During operation, all indoor units and outdoor units belonging to the same system must be kept energized status. Otherwise, the unit can't operate normally.

### 4.9.1 External wiring diagram



### **NOTICE**

The maximum outdoor unit quantity "n" is decided by the combination from of outdoor unit. Please refer to the actual requirement of unit for the earthing position.

Fig.4.9.1

## 5 Check Items after Installation and Trial Run

### 5.1 Check Items after Installation

| Check items  | Possible conditions due to improper installation                          | Check |
|--|---|-------|
| Each part of the unit is installed securely?   | Unit may drop, shake or emit noise  |       |
| Gas leakage test is taken or not?  | Insufficient cooling (heating) capacity                                   |       |
| Unit gets proper thermal insulation or not?  | There may be condensation and dripping.                                   |       |
| Drainage is smooth or not?   | There may be condensation and dripping.                                   |       |
| Is the voltage in accordance with the rated voltage specified on the nameplate?        | Unit may have malfunction or components may get damaged.                  |       |
| Is the electric wiring and pipe connection installed correctly?                        | Unit may have malfunction or components may get damaged.                  |       |
| Unit is securely grounded or not?  | Electrical leakage  |       |
| Power cord meets the required specification?   | Unit may have malfunction or components may get damaged.                  |       |
| Is the air inlet/outlet blocked?   | Insufficient cooling (heating) capacity                                   |       |
| Length of refrigerant pipe and the charging amount of refrigerant are recorded or not? | The refrigerant charging amount is not accurate.                          |       |
| Is the address code of outdoor modules and the code of module quantity correct?        | The unit cannot run normally. Communication malfunction might happen.     |       |
| Is the address code of indoor units and wired controller correct?                      | The unit cannot run normally. Communication malfunction might happen.     |       |
| Has the communication line been connected correctly?                                   | The unit cannot run normally. Communication malfunction might happen.     |       |
| Is the piping connection and valve status correct?                                     | The unit cannot run normally. The unit might be damaged.                  |       |
| Is the phase sequence of external power cord correct?                                  | The unit cannot run normally. Phase sequence error may happen.            |       |
| Whether the engineering piping work and wiring holes are sealed?                       | Maybe there are mice biting the wires, which is the cause of malfunction. |       |

### 5.2 Trial Run

**NOTICE!** During debugging, one and only one module must be set as a master module.

When no special requirement is needed, no need to set other functions. Unit can operate according to ex-factory settings. When special requirement is needed, please read the Service Manual or Debugging and Maintenance Manual.

#### 5.2.1 Preparation before trial run

- (1) The power supply should be turned on only after finishing all the installation.
- (2) All the control wires and cables are connected correctly and safely. Completely open the gas and liquid valves.
- (3) All the objects like metal filing, thrum and clip should be cleared after installation.
- (4) Check if the unit appearance and piping system is damaged or not due to transportation.
- (5) Check if the terminals of electrical element is loose and the phase sequence is correct or not.
- (6) Check the valve: For single-module unit, fully open the gas and liquid valve and close oil balance valve; for dual/three module unit, fully open the gas, liquid valve and oil balance valve.

## 5.2.2 Trial run

### 5.2.2.1 Notices

- (1) Before test operation, make sure unit is power on and compressor has been preheated for more than 8 hours. Touch the unit to check whether it's normally preheated. Start test operation after unit is normally preheated, otherwise compressor might be damaged. Debugging must be performed by professional technicians or under the guide of professional technicians.




Fig.5.2.1

- (2) When debugging starts, system will operate according to the ambient temperature.
  - 1) When outdoor temperature is above 20°C(68°F), debugging shall be in cooling mode.
  - 2) When outdoor temperature is below 20°C(68°F), debugging shall be in heating mode.
- (3) Before debugging, confirm again whether the cut-off valve of each basic module is fully turned on.
- (4) During debugging, front panel of the outdoor unit must be fully closed; otherwise, debugging accuracy will be affected (see below).




Fig.5.2.2

- (5) Before debugging, make sure the needed amount of refrigerant has been added to the pipe or at least 70% of the needed refrigerant has been added.

## (6) Description of each stage of debugging progress:

| Description of each stage of debugging progress |                |                |               |                |                         |                |   |
|---|----------------|----------------|---------------|----------------|-------------------------|----------------|---|
| —   | Debugging code |                | Progress code |                | Status code             |                | Meaning   |
| Progress  | LED1           |                | LED2          |                | LED3                    |                |   |
|   | Code           | Display status | Code          | Display status | Code                    | Display status |   |
| 01_Set master unit                              | db             | On             | 01            | On             | A0                      | On             | System is not debugged.   |
|   | db             | On             | 01            | On             | CC                      | On             | Master unit hasn't been set. Please set it.   |
|   | db             | On             | 01            | On             | CF                      | On             | Master unit is two or more than two. Please reset.  |
|   | db             | On             | 01            | On             | OC                      | On             | Master unit has been set successfully. Next step will start automatically.  |
| 02_Allocate addresses                           | db             | On             | 02            | On             | Ad                      | Blink          | System is allocating addresses.   |
|   | db             | On             | 02            | On             | L7                      | Blink          | No master indoor unit. Please the maser indoor unit. If master indoor unit is not set within 1min, the system will set it randomly.   |
|   | db             | On             | 02            | On             | OC                      | On             | Address allocation is finished. Next step will start automatically.   |
| 03_Confirm the quantity of module               | db             | On             | 03            | On             | 01~04                   | Blink          | LED3 displays the quantity of module. In this case, please confirm if the quantity is correct manually.   |
|   | db             | On             | 03            | On             | OC                      | On             | System has confirmed the quantity of module. Next step will start automatically.  |
| 04_Confirm the quantity of IDU                  | db             | On             | 04            | On             | 01~80                   | Blink          | LED3 displays the quantity of IDU. In this case, please confirm if the quantity is correct manually.  |
|   | db             | On             | 04            | On             | OC                      | On             | System has confirmed the quantity of IDU. Next step will start automatically.   |
| 05_Internal communication detection             | db             | On             | 05            | On             | C2                      | On             | Communication between master ODU and inverter compressor driver has error.  |
|   | db             | On             | 05            | On             | C3                      | On             | Communication between master ODU and inverter fan driver has error.   |
|   | db             | On             | 05            | On             | CH                      | On             | Rated capacity ratio between IDU and ODU is too high.   |
|   | db             | On             | 05            | On             | CL                      | On             | Rated capacity ratio between IDU and ODU is too low.  |
|   | db             | On             | 05            | On             | OC                      | On             | System detection is done. Next step will start automatically.   |
| 06_Detect outdoor components                    | db             | On             | 06            | On             | Related error code      | On             | System detects that outdoor components have error.  |
|   | db             | On             | 06            | On             | OC                      | On             | System detects no error on outdoor components. Next step will start automatically.  |
| 07_Detect indoor components                     | db             | On             | 07            | On             | XXXX/Related error code | On             | System detects error on indoor components. XXXX means the project code of IDU with error. 3s later, related error code will be displayed. For instance, if No.100 IDU has d5 error, then the LED3 will display circularly as below: 01(2s later), 00(2s later), d5. |
|   | db             | On             | 07            | On             | OC                      | On             | System detects no error on indoor components. Next step will start automatically.   |



Heat Recovery DC Inverter VRF

| Description of each stage of debugging progress          |                |                |               |                |                    |                |   |
|--|----------------|----------------|---------------|----------------|--------------------|----------------|---|
| —  | Debugging code |                | Progress code |                | Status code        |                | Meaning   |
| Progress   | LED1           |                | LED2          |                | LED3               |                |   |
|  | Code           | Display status | Code          | Display status | Code               | Display status |   |
| 08_Confirm preheated compressor                          | db             | On             | 08            | On             | U0                 | On             | Preheat time for compressor is less than 8 hours.   |
|  | db             | On             | 08            | On             | OC                 | On             | Compressor has been preheated for 8 hours. Next step will start automatically.  |
| 09_Refrigerant judgments before startup                  | db             | On             | 09            | On             | U4                 | On             | System is lack of refrigerant. System stops with balance equalizing pressure lower than 0.3Mpa.   |
|  | db             | On             | 09            | On             | OC                 | On             | Refrigerant is normal. Next step will start automatically.  |
| 10_Status judgments of outdoor valves before startup     | db             | On             | 10            | On             | ON                 | On             | Outdoor valves are being inspected.   |
|  | db             | On             | 10            | On             | U6                 | On             | Outdoor valves are not fully opened.  |
|  | db             | On             | 10            | On             | OC                 | On             | Outdoor valves open normally.   |
| 11_Calculate refrigerant charging amount status manually | db             | On             | 11            | On             | AE                 | On             | The refrigerant charging amount status is manual calculation status(additional refrigerant charging amount must be calculated correctly).   |
| 12_Confirm debugging startup                             | db             | On             | 12            | On             | AP                 | Blink          | Ready for units to start debugging.   |
|  | db             | On             | 12            | On             | AE                 | On             | The unit has been set in debugging operation status of manual calculation of refrigerant charging amount.   |
| 13_  | —              | —              | —             | —              | —                  | —              | No meaning.   |
| 14_  | —              | —              | —             | —              | —                  | —              | No meaning.   |
| 15_Cooling debugging                                     | db             | On             | 15            | On             | AC                 | On             | Debugging for cooling mode. (Debugging operation mode, the system will select automatically with no need of manual setting).  |
|  | db             | On             | 15            | On             | Related error code | On             | Malfunction occurs when debugging for cooling mode.   |
|  | db             | On             | 15            | On             | J0                 | On             | Malfunction of other module occurs when debugging for cooling mode.   |
|  | db             | On             | 15            | On             | U9                 | On             | Pipeline or valve of outdoor unit is faulty.  |
|  | db             | On             | 15            | On             | XXXX /U8           | On             | System detects error on indoor pipeline. XXXX means the project code of IDU with error. 3s later, U8 will be displayed. For instance, if No.100 IDU has U8 error, then the LED3 will display circularly as below: 01(2s later), 00(2s later), U8. |

| Description of each stage of debugging progress |                |                |               |                |                    |                |   |
|---|----------------|----------------|---------------|----------------|--------------------|----------------|---|
| —   | Debugging code |                | Progress code |                | Status code        |                | Meaning   |
| Progress  | LED1           |                | LED2          |                | LED3               |                |   |
|   | Code           | Display status | Code          | Display status | Code               | Display status |   |
| 16_Heating debugging                            | db             | On             | 16            | On             | AH                 | On             | Debugging for heating mode. (Debugging operation mode, the system will select automatically with no need of manual setting).  |
|   | db             | On             | 16            | On             | Related error code | On             | Malfunction occurs when debugging for heating mode.   |
|   | db             | On             | 16            | On             | J0                 | On             | Malfunction of other module occurs when debugging for heating mode.   |
|   | db             | On             | 16            | On             | U9                 | On             | Pipeline or valve of outdoor unit is faulty.  |
|   | db             | On             | 16            | On             | XXXX /U8           | On             | System detects error on indoor pipeline. XXXX means the project code of IDU with error. 3s later, U8 will be displayed. For instance, if No.100 IDU has U8 error, then the LED3 will display circularly as below: 01(2s later), 00(2s later), U8. |
| 17_Debugging completion status                  | 01<br>~04      | On             | OF            | On             | OF                 | On             | Debugging operation has been done and the unit is in standby status. LED1 displays module address. LED2 and LED3 display "OF".  |

### 5.2.2.2 Debugging operation mode

System has two debugging modes: one is direct operation on main board of outdoor units while the other is PC operation via special software. In PC software debugging, indoor/outdoor parameters can be displayed and historical data can be recorded and inquired (Operation details can be found in relevant instruction manuals).

#### (1) Debugging through operation on main board of outdoor units

In this debugging mode, following debugging functions are included on the main board:

Step 1: front panel of the outdoor units must be fully closed. Open the debugging window of each basic module;

Step 2: disconnect power for outdoor units. According to design requirements of external static pressure, set up corresponding static pressure mode for the units. Setting methods can be seen in Outdoor Fan Static Pressure Setup SA6\_ESP\_S;

Step 3: disconnect power for outdoor units and set one module as a master unit. Setting methods can be seen in Master Unit Setup SA8\_MASTER\_S;

Step 4: Connect power for all indoor units. Make sure all IDUs are power on. Then all outdoor modules will display "Debugging not enabled";

Step 5: Find the module with "01" module address to be the master module. Hold SW7 button on the master module for at least 5s to enable debugging;

Step 6: Wait. Unit will then start progress 01 and 02; in progress 01, if master unit is not correctly set, progress 01 will show the following errors:

| —                         | Debugging Code |                | Progress Code |                | Status Code |                | Meaning   |
|---------------------------|----------------|----------------|---------------|----------------|-------------|----------------|---|
| Progress                  | LED1           |                | LED2          |                | LED3        |                |   |
|                           | Code           | Display status | Code          | Display status | Code        | Display status |   |
| 01_01 Set up master unit: | db             | light          | 01            | light          | CC          | light          | System doesn't have master unit. Reset master unit.   |
|                           | db             | light          | 01            | light          | CF          | light          | More than 2 master units are set. Reset master unit.  |
|                           | db             | light          | 01            | light          | OC          | light          | Master unit is successfully set. Start next progress. |

According to the above errors, reset the master unit as instructed in Master Unit Setup SA8\_MASTER\_S. After reset is finished, start debugging again.

Step 7: in progress 03, the quantity of modules needs to be confirmed manually. Main board of each module will display:

| —                      | Debugging code |                | Progress code |                | Status code         |                |
|------------------------|----------------|----------------|---------------|----------------|---------------------|----------------|
| Progress               | LED1           |                | LED2          |                | LED3                |                |
|                        | Code           | Display status | Code          | Display status | Code                | Display status |
| 03_Quantity of modules | db             | light          | 03            | light          | Quantity of modules | blink          |

If the quantity displayed is the same with actual quantity, then press SW7 confirmation button on the master unit to confirm it. Unit will start next progress:

| —                                  | Debugging code |                | Progress code |                | Status code |                |
|------------------------------------|----------------|----------------|---------------|----------------|-------------|----------------|
| Progress                           | LED1           |                | LED2          |                | LED3        |                |
|                                    | Code           | Display status | Code          | Display status | Code        | Display status |
| 03_Confirm the quantity of modules | db             | light          | 03            | light          | OC          | light          |

If the quantity displayed is different from actual quantity, then disconnect power and check whether communication wire among each module is correctly connected. After the check, start debugging again.

Step 8: in progress 04, the quantity of IDUs needs to be confirmed manually. Main board of each module will display:

| —                               | Debugging code |                | Progress code |                | Status code                |                |
|---------------------------------|----------------|----------------|---------------|----------------|----------------------------|----------------|
| Progress                        | LED1           |                | LED2          |                | LED3                       |                |
|                                 | Code           | Display status | Code          | Display status | Code                       | Display status |
| 04_Confirm the quantity of IDUs | db             | Light          | 04            | Light          | Quantity of connected IDUs | blink          |

If the quantity displayed is the same with actual quantity, then press SW7 confirmation button on the master unit to confirm it. Unit will start next progress:

| —                               | Debugging code |                | Progress code |                | Status code |                |
|---------------------------------|----------------|----------------|---------------|----------------|-------------|----------------|
| Progress                        | LED1           |                | LED2          |                | LED3        |                |
|                                 | Code           | Display status | Code          | Display status | Code        | Display status |
| 04_Confirm the quantity of IDUs | db             | Light          | 04            | Light          | OC          | Light          |

Step 9: progress 05 is “Detect internal communication”

If no error is detected, system will display as below and then start next progress.

| —                                | Debugging code |                | Progress code |               | Status code |                | Meaning                                     |
|----------------------------------|----------------|----------------|---------------|---------------|-------------|----------------|---|
| progress                         | LED1           |                | LED2          |               | LED3        |                |   |
|                                  | Code           | Display status | code          | Display tatus | Code        | Display status |   |
| 05_Detect internal communication | db             | Light          | 05            | Light         | OC          | Light          | Detection is finished. Start next progress. |

If error is detected, system will stay at current progress. Error has to be solved manually. Below are relevant errors:

| —                                | Debugging code |                | Progress code |                | Status code |                | Meaning  |
|----------------------------------|----------------|----------------|---------------|----------------|-------------|----------------|--|
| progress                         | LED1           |                | LED2          |                | LED3        |                |  |
|                                  | Code           | Display status | code          | Display status | Code        | Display status |  |
| 05_Detect internal communication | db             | Light          | 05            | Light          | C2          | Light          | System detects “driven communication error between master unit and inverter compressor”. |
|                                  | db             | Light          | 05            | Light          | C3          | Light          | System detects “driven communication error between master unit and inverter fan”.        |
|                                  | db             | Light          | 05            | Light          | CH          | Light          | IDU/ODU “high proportion of rated capacity”.   |
|                                  | db             | Light          | 05            | Light          | CL          | Light          | IDU/ODU “low proportion of rated capacity”.  |

Elimination methods of above errors can be found in Troubleshooting.

Step 10: progress 06 is “Detect outdoor components”

If no error is detected, system will display as below and then start next progress.

| —                            | Debugging code |                | Progress code |                | Status code |                | Meaning  |
|------------------------------|----------------|----------------|---------------|----------------|-------------|----------------|--|
| progress                     | LED1           |                | LED2          |                | LED3        |                |  |
|                              | Code           | Display status | code          | Display status | Code        | Display status |  |
| 06_Detect outdoor components | db             | Light          | 06            | Light          | OC          | Light          | No error is detected in outdoor components. Start next progress. |

If error is detected, system will stay at current progress. Error has to be solved manually. Below is relevant error:

| —                            | Debugging code |                | Progress code |                | Status code |                | Meaning                                     |
|------------------------------|----------------|----------------|---------------|----------------|-------------|----------------|---|
| progress                     | LED1           |                | LED2          |                | LED3        |                |   |
|                              | Code           | Display status | code          | Display status | Code        | Display status |   |
| 06_Detect outdoor components | db             | Light          | 06            | Light          | Error code  | Light          | System detects error in outdoor components. |

Elimination methods of above error can be found in Troubleshooting.

Step11: progress 07 is “Detect indoor components”

If no error is detected, system will display as below and then start next progress.

| —                           | Debugging code |                | Progress code |                | Status code |                | Meaning   |
|-----------------------------|----------------|----------------|---------------|----------------|-------------|----------------|---|
| progress                    | LED1           |                | LED2          |                | LED3        |                |   |
|                             | Code           | Display status | code          | Display status | Code        | Display status |   |
| 07_Detect indoor components | db             | Light          | 07            | Light          | OC          | Light          | No error is detected in indoor components. Start next progress. |

If error is detected, system will stay at current progress. Error has to be solved manually. Below is relevant error:

| —                           | Debugging code |                | Progress code |                | Status code        |                | Meaning                                    |
|-----------------------------|----------------|----------------|---------------|----------------|--------------------|----------------|--|
| progress                    | LED1           |                | LED2          |                | LED3               |                |  |
|                             | Code           | Display status | code          | Display status | Code               | Display status |  |
| 07_Detect indoor components | db             | Light          | 07            | Light          | XXXX or Error code | Light          | System detects error in indoor components. |

XXXX is the project No. of the faulted IDU. 3s later, relevant error code is displayed. For example, IDU No. 100 has d5 error, then LED3 displays like this: 01 (2s later) 00 (2s later) d5, and repeat again.

Elimination methods of above error can be found in Troubleshooting.

Step 12: progress 08 is “Confirm preheated compressor”

If more than 8h of preheat time is detected, system will display as below and start next progress.

| —                               | Debugging code |                | Progress code |                | Status code |                | Meaning   |
|---------------------------------|----------------|----------------|---------------|----------------|-------------|----------------|---|
| progress                        | LED1           |                | LED2          |                | LED3        |                |   |
|                                 | Code           | Display status | code          | Display status | Code        | Display status |   |
| 08_Confirm preheated compressor | db             | Light          | 08            | Light          | OC          | Light          | Preheat time for compressor is 8h. Start next progress. |

If less than 8h of preheat time is detected, system will give error alarm and display as below. Then press SW7 confirmation button to skip the wait time and start next progress. But this will cause force start of the compressor, which may damage the compressor.

| —                               | Debugging code |                | Progress code |                | Status code |                | Meaning                                      |
|---------------------------------|----------------|----------------|---------------|----------------|-------------|----------------|--|
| progress                        | LED1           |                | LED2          |                | LED3        |                |  |
|                                 | Code           | Display status | code          | Display status | Code        | Display status |  |
| 08_Confirm preheated compressor | db             | Light          | 08            | Light          | UO          | Light          | Preheat time for compressor is less than 8h. |

Step 13: progress 09 is “Refrigerant judgments before startup”

If the refrigerant quantity inside the system meets the requirement of operation startup, system will display as below and start next progress.

| —                                       | Debugging code |                | Progress code |                | Status code |                | Meaning  |
|---|----------------|----------------|---------------|----------------|-------------|----------------|--|
| progress                                | LED1           |                | LED2          |                | LED3        |                |  |
|   | Code           | Display status | code          | Display status | Code        | Display status |  |
| 09_Refrigerant judgments before startup | db             | Light          | 09            | Light          | OC          | Light          | System refrigerant is normal. Start next progress. |

If there's no or not enough refrigerant in the system to meet the requirement of operation startup, system will display U4 "refrigerant shortage protection" and fails to start next progress. Then check if there's any leakage or add refrigerant inside until error eliminated.

| —                                       | Debugging code |                | Progress code |                | Status code |                | Meaning   |
|---|----------------|----------------|---------------|----------------|-------------|----------------|---|
| progress                                | LED1           |                | LED2          |                | LED3        |                |   |
|   | Code           | Display status | code          | Display status | Code        | Display status |   |
| 09_Refrigerant judgments before startup | db             | Light          | 09            | Light          | O4          | Light          | System refrigerant is not enough. System downtime equilibrium pressure is lower than 0.3MPa(4-2/5psig). |

Step 14: progress 10 is "Status judgments of outdoor valves before startup"

If master unit displays below, status judgments are enabled.

| —  | Debugging code |                | Progress code |                | Status code |                | Meaning                             |
|--|----------------|----------------|---------------|----------------|-------------|----------------|-------------------------------------|
| progress   | LED1           |                | LED2          |                | LED3        |                |                                     |
|  | Code           | Display status | code          | Display status | Code        | Display status |                                     |
| 10_Status judgments of outdoor valves before startup | db             | Light          | 10            | Light          | ON          | Light          | Outdoor valves are being turned on. |

If unit detects that valve status is not normal, it will display as below:

| —  | Debugging code |                | Progress code |                | Status code |                | Meaning                                 |
|--|----------------|----------------|---------------|----------------|-------------|----------------|---|
| progress   | LED1           |                | LED2          |                | LED3        |                |   |
|  | Code           | Display status | code          | Display status | Code        | Display status |   |
| 10_Status judgments of outdoor valves before startup | db             | Light          | 10            | Light          | U6          | Light          | Outdoor valves are not fully turned on. |

Then check the big and small valves whether they are fully turned on. After the check, press SW6 return button to restart the judgments.

If unit detects that valve status is normal, it will display as below and start next progress.

| —  | Debugging code |                | Progress code |                | Status code |                | Meaning                                |
|--|----------------|----------------|---------------|----------------|-------------|----------------|--|
| progress   | LED1           |                | LED2          |                | LED3        |                |  |
|  | Code           | Display status | code          | Display status | Code        | Display status |  |
| 10_Status judgments of outdoor valves before startup | db             | Light          | 10            | Light          | OC          | Light          | Outdoor valves are turned on normally. |

Step 15: progress 11 is "Calculate refrigerant quantity manually"

No need to operate. System will start next progress.

Step 16: progress 12 is "Confirm debugging startup"

In order to make sure all preparation work is done before startup, this step is designed for user to confirm the startup again. Operate as below:

If master unit displays as below, system is waiting for confirmation signal.

| —  | Debugging code |                | Progress code |                | Status code |                | Meaning                             |
|--|----------------|----------------|---------------|----------------|-------------|----------------|-------------------------------------|
| progress   | LED1           |                | LED2          |                | LED3        |                |                                     |
|  | Code           | Display status | code          | Display status | Code        | Display status |                                     |
| 12_Status judgments of outdoor valves before startup | db             | Light          | 12            | Light          | AP          | Blink          | Ready for units to start debugging. |

If it's confirmed, press SW7 confirmation button. Unit will display as below and start next progress.

| —  | Debugging code |                | Progress code |                | Status code |                | Meaning   |
|--|----------------|----------------|---------------|----------------|-------------|----------------|---|
| progress   | LED1           |                | LED2          |                | LED3        |                |   |
|  | Code           | Display status | code          | Display status | Code        | Display status |   |
| 12_Status judgments of outdoor valves before startup | db             | Light          | 12            | Light          | AE          | Light          | Manual calculation of refrigerant quantity is set up. |

Step 17: after unit is confirmed to start debugging, system select cooling/heating mode according to ambient temperature.

A If cooling mode is selected, relevant display is as below:

| —                    | Debugging code |                | Progress code |                | Status code |                | Meaning   |
|----------------------|----------------|----------------|---------------|----------------|-------------|----------------|---|
| progress             | LED1           |                | LED2          |                | LED3        |                |   |
|                      | Code           | Display status | code          | Display status | Code        | Display status |   |
| 15_Cooling debugging | db             | Light          | 15            | Light          | AC          | Light          | Debugging is enabled in cooling mode (debugging mode, auto-selected by system).   |
|                      | db             | Light          | 15            | Light          | Error code  | Light          | Error occurs during debugging in cooling mode.  |
|                      | db             | Light          | 15            | Light          | J0          | Light          | Error of other modules occurs during debugging in cooling mode.   |
|                      | db             | Light          | 15            | Light          | U9          | Light          | Outdoor pipeline and valves are not normal.   |
|                      | db             | Light          | 15            | Light          | XXXX /U8    | Light          | System detects error in indoor pipeline. XXXX is the project No. of the faulted IDU. 3s later, error code U8 is displayed. For example, IDU No. 100 has U8 error, then LED3 displays like this: 01 (2s later) 00 (2s later) U8, and repeat again. |

B If heating mode is selected, relevant display is as below:

| —                    | Debugging code |                | Progress code |                | Status code |                | Meaning   |
|----------------------|----------------|----------------|---------------|----------------|-------------|----------------|---|
| progress             | LED1           |                | LED2          |                | LED3        |                |   |
|                      | Code           | Display status | code          | Display status | Code        | Display status |   |
| 16_Heating debugging | db             | Light          | 16            | Light          | AE          | Light          | Debugging is enabled in heating mode (debugging mode, auto-selected by system).   |
|                      | db             | Light          | 16            | Light          | Error code  | Light          | Error occurs during debugging in heating mode.  |
|                      | db             | Light          | 16            | Light          | J0          | Light          | Error of other modules occurs during debugging in heating mode.   |
|                      | db             | Light          | 16            | Light          | U9          | Light          | Outdoor pipeline and valves are not normal.   |
|                      | db             | Light          | 16            | Light          | XXXX /U8    | Light          | System detects error in indoor pipeline. XXXX is the project No. of the faulted IDU. 3s later, error code U8 is displayed. For example, IDU No. 100 has U8 error, then LED3 displays like this: 01 (2s later) 00 (2s later) U8, and repeat again. |

Step 18: if there's no error during operation for about 40min, system will automatically confirm that debugging is finished and then stop. System resumes standby condition and displays as below:

| —                     | Debugging code |                | Progress code |                | Status code |                | Meaning  |
|-----------------------|----------------|----------------|---------------|----------------|-------------|----------------|--|
| progress              | LED1           |                | LED2          |                | LED3        |                |  |
|                       | Code           | Display status | code          | Display status | Code        | Display status |  |
| 17_Debugging finished | 01-04          | Light          | OF            | Light          | OF          | Light          | Debugging is finished. System is on standby condition. LED1 displays module address. LED2 and LED3 display "OF". |

Step 19: after debugging is finished, some functions can be set up according to project's actual needs. For specific details, please refer to System Functions Setup. If no special requirements, skip this step.

Step 20: deliver the product to user and inform user about usage precautions.



## 5.2.3 Appendix: judgment reference of normal operational parameters

| Reference of Debug Parameters |                   |  |        |  |
|-------------------------------|-------------------|--|--------|--|
| No.                           | Debug item        | Parameter name                               | Unit   | Reference  |
| 1                             | System parameters | Outdoor ambient temp                         | °C(°F) | —  |
| 2                             |                   | Discharge tube temp of inverter compressor 1 | °C(°F) | <ul style="list-style-type: none"> <li>When system compressor starts up, temp of discharge tube or casing top in cooling mode is within 70~95°C (158~203°F), and at least 10°C (50°F) higher than system high pressure saturation temp; temp in heating mode is within 65~80°C (149~176°F), and at least 10°C (50°F) higher than system high pressure saturation temp.</li> <li>When inverter compressor starts but inverter compressor 2 stops, the discharge tube temperature of inverter compressor 2 is almost the same with ambient temp.</li> </ul>                              |
| 3                             |                   | Casing top temp of inverter compressor 1     | °C(°F) |  |
| 4                             |                   | Discharge tube temp of inverter compressor 2 | °C(°F) |  |
| 5                             |                   | Casing top temp of inverter compressor 2     | °C(°F) |  |
| 6                             |                   | Defrost temp 1                               | °C(°F) |  |
| 7                             |                   | System high pressure                         | °C(°F) | <ul style="list-style-type: none"> <li>System's normal high pressure value is within 20~55°C (68~131°F) According to the change in ambient temp and system operational capacity, system's high pressure value is 10~40°C (50~104°F) higher than ambient temp. The higher ambient temp is, the smaller temp difference is.</li> <li>When ambient temp is 25~35°C (77~95°F), system's high pressure value in cooling mode is 44~53°C (111.2~127.4°F).</li> <li>When ambient temp is -5~10°C (23~50°F), system's high pressure value in heating mode is 40~52°C (104~125.6°F).</li> </ul> |
| 8                             |                   | System low pressure                          | °C(°F) | <ul style="list-style-type: none"> <li>When ambient temp is 25~35°C (77~95°F), system's low pressure value in cooling mode is 0~8°C (32~46.4°F).</li> <li>When ambient temp is -5~10°C (23~50°F), system's low pressure value in heating mode is -15~5°C (5~41°F).</li> </ul>  |
| 9                             |                   | Opening angle of heating EXV                 | PLS    | <ul style="list-style-type: none"> <li>In cooling mode, heating electronic expansion valve remains 480PLS.</li> <li>In heating mode, the opening angle of adjustable electronic expansion valve varies within 120~480PLS.</li> </ul>   |
| 10                            |                   | Operating freq. of inverter compressor*      | Hz     | Varies from 20Hz to 100Hz  |
| 11                            |                   | IPM temp of inverter compressor              | °C(°F) | When ambient temp is lower than 35°C (95°F), IPM temp is below 85°C (185°F). Highest temp won't be above 95°C(203°F).  |
| 12                            |                   | Inverter compressor driven bus voltage       | V      | Normal bus voltage is 1.414 times of power voltage. For example, if 3-phase power voltage is 460V, then the bus voltage after rectification is: 460V×1.414=650V. It's normal if actual voltage varies 15V from the calculated voltage.   |
| 13                            |                   | Operating freq of fan motor                  | Hz     | Adjusts in 0~65Hz according to system pressure.  |

| Reference of Debug Parameters |                         |                    |   |  |
|-------------------------------|-------------------------|--------------------|---|--|
| No.                           | Debug item              | Parameter name     | Unit                                      | Reference  |
| 14                            | System parameters       | IDU                | Ambient temp of IDU                       | °C(°F) —   |
| 15                            |                         |                    | Inlet tube temp of indoor heat exchanger  | °C(°F) • According to different ambient temp, for a same IDU under cooling mode, inlet tube temp will be 1~7°C (33.8~44.6°F) lower than outlet tube temp.                                    |
| 16                            |                         |                    | Outlet tube temp of indoor heat exchanger | °C(°F) • For a same IDU under heating mode, inlet tube temp will be 10~20°C (50~68°F) lower than outlet tube temp.   |
| 17                            |                         |                    | Opening angle of indoor EXV               | PLS Adjusts opening angle automatically in 200~2000PLS or 70~480PLS.   |
| 18                            | Communication parameter | Communication data | —   | Quantity of IDU and ODU detected by software is the same with actual quantity. No communication error.   |
| 19                            | Drainage system         | —                  | —   | IDU can drain water out completely and smoothly. Condensate pipe has no backward slope of water. Water of ODU can be drained completely through drainage pipe. No water drop from unit base. |
| 20                            | Others                  | —                  | °C(°F)                                    | Compressor and indoor/outdoor fan motor has no strange noise. Unit operates normally.  |

\*Different compressor operating frequency ranges are different.

## 6 Common Malfunction and Troubleshooting

Check the following items before contacting for repair.

| Phenomenon                      | Reason  | Measure  |
|---------------------------------|---|--|
| The unit doesn't run.           | Without power supply                                      | Connect to power supply  |
|                                 | Voltage is too low  | Check if the voltage is within rating range                      |
|                                 | Broken fuse or breaker trips off                          | Replace fuse or connect breaker                                  |
|                                 | Insufficient energy of remote controller                  | Replace new battery  |
|                                 | Remote controller is out of control scope                 | Control scope is within 8m                                       |
| Unit runs but stop immediately. | Air intake or outlet of indoor or outdoor unit is blocked | Remove obstruction   |
| Abnormal cooling or heating.    | Air intake or outlet of indoor or outdoor unit is blocked | Remove obstruction   |
|                                 | Improper temperature setting                              | Adjust setting at wireless remote controller or wired controller |
|                                 | Fan speed is set too low                                  | Adjust setting at wireless remote controller or wired controller |
|                                 | Wind direction is not correct                             | Adjust setting at wireless remote controller or wired controller |
|                                 | Door or windows are opened                                | Close the door or windows  |
|                                 | Direct sunshine   | Draw curtain or louver   |
|                                 | Too many people in the room                               | —  |
|                                 | Too many heat resources in the room                       | Reduce heat resources  |
| Filter is blocked for dirt      | Clean the filter  |  |

**⚠ WARNING**

(1) When installing remote monitor or central controller, displacement on indoor units' project codes must be made. Otherwise, there will be collision malfunction of the project codes. For detail operation methods, please refer to the Installation and Maintenance Manual.

(2) If problem cannot be solved after checking the above items, please contact Gree service center and show phenomena and models.

Following circumstance are not malfunction.

| "Malfunction"                           |   | Reason   |
|---|---|--|
| Unit doesn't run                        | When unit is started immediately after it is just turned off                | Overload protection switch makes it run after 3 minutes delay  |
|   | When power is turned on   | Standby operating for about 1 minute   |
| Mist comes from the unit                | Under cooling   | Indoor high humidity air is cooled rapidly   |
| Noise is emitted                        | Slight cracking sound is heard when just turned on                          | It is noise when electronic expansion valve initialization   |
|   | There is consecutive sound when cooling                                     | That's sound for gas refrigerant flowing in unit   |
|   | There is sound when unit starts or stops                                    | That's sound for gas refrigerant stops to flow   |
|   | There is slight and consecutive sound when unit is running or after running | That's sound for operation of drainage system  |
|   | Cracking sound is heard when unit is operating and after operating          | That's sound caused by expansion of panel and other parts due to temperature change  |
| The unit blows out duct                 | When unit runs after no operation for a long period                         | Dust in indoor unit is blew out  |
| The unit emits odor                     | Operating   | The room odor absorbed by the unit is blew out again   |
| Indoor unit still runs after switch off | After every indoor unit receive "stop" signal, fan will keep running        | Indoor fan motor will keep running 20-70s so as to take good use of excess cooling and heating and prepare for next operation  |
| Mode conflict                           | COOL or HEAT mode cannot be operated  | When the indoor operating mode conflicts with that of outdoor unit, indoor fault indicator will flash and conflict will be shown on the wired controller after 5 minutes. Indoor unit stops to run and meanwhile change outdoor operating mode as the same as that of indoor unit, then the unit will go back to normal. COOL mode doesn't conflict with DRY mode. FAN mode doesn't conflict with any mode |

## 7 Error Indication

Inquiry method of error indication: combine division symbol and content symbol to check the corresponding error.

Indoor:

| Error Code | Content   | Error Code | Content  |
|------------|---|------------|--|
| L0         | Malfunction of IDU  | d2         | Malfunction of lower water temperature sensor of water tank  |
| L1         | Protection of indoor fan  | d3         | Malfunction of ambient temperature sensor                    |
| L2         | Auxiliary heating protection  | d4         | Malfunction of entry-tube temperature sensor                 |
| L3         | Water-full protection   | d6         | Malfunction of exit-tube temperature sensor                  |
| L4         | Abnormal power supply for wired controller  | d7         | Malfunction of humidity sensor                               |
| L5         | Freeze prevention protection  | d8         | Malfunction of water temperature sensor                      |
| L7         | No main IDU   | d9         | Malfunction of jumper cap                                    |
| L8         | Power supply is insufficient  | dA         | Web address of IDU is abnormal                               |
| L9         | For single control over multiple units, number of IDU is inconsistent                 | dH         | PCB of wired controller is abnormal                          |
| LA         | For single control over multiple units, IDU series is inconsistent                    | dC         | Setting capacity of DIP switch code is abnormal              |
| LH         | Alarm due to bad air quality  | dL         | Malfunction of air outlet temperature sensor                 |
| LC         | IDU is not matching with outdoor unit   | dE         | Malfunction of indoor CO <sub>2</sub> sensor                 |
| LL         | Malfunction of water flow switch  | dF         | Malfunction of upper water temperature sensor of water tank  |
| LE         | Rotation speed of EC DC water pump is abnormal  | dJ         | Malfunction of backwater temperature sensor                  |
| LF         | Malfunction of shunt valve setting  | dP         | Malfunction of inlet tube temperature sensor of generator    |
| LJ         | Setting of functional DIP switch code is wrong  | dU         | Malfunction of drainage pipe temperature sensor of generator |
| LP         | Zero-crossing malfunction of PG motor   | Db         | Debugging status   |
| LU         | Indoor unit's branch is not inconsistent for one-to-more unit of heat recovery system | Dd         | Malfunction of solar power temperature sensor                |
| d1         | Indoor PCB is poor  | Dn         | Malfunction of swing parts                                   |

## Outdoor:

| Error Code | Content   | Error Code | Content  |
|------------|---|------------|--|
| E0         | Malfunction of ODU                                      | FH         | Current sensor of compressor 1 is abnormal                             |
| E1         | High-pressure protection                                | FC         | Current sensor of compressor 2 is abnormal                             |
| E2         | Discharge low-temperature protection                    | FL         | Current sensor of compressor 3 is abnormal                             |
| E3         | Low-pressure protection                                 | FE         | Current sensor of compressor 4 is abnormal                             |
| E4         | High discharge temperature protection of compressor     | FF         | Current sensor of compressor 5 is abnormal                             |
| J0         | Protection for other modules                            | FJ         | Current sensor of compressor 6 is abnormal                             |
| J1         | Over-current protection of compressor 1                 | FP         | Malfunction of DC motor  |
| J2         | Over-current protection of compressor 2                 | FU         | Malfunction of casing top temperature sensor of compressor 1           |
| J3         | Over-current protection of compressor 3                 | Fb         | Malfunction of casing top temperature sensor of compressor 2           |
| J4         | Over-current protection of compressor 4                 | Fd         | Malfunction of exit tube temperature sensor of mode exchanger          |
| J5         | Over-current protection of compressor 5                 | Fn         | Malfunction of inlet tube temperature sensor of mode exchanger         |
| J6         | Over-current protection for compressor 6                | b1         | Malfunction of outdoor ambient temperature sensor                      |
| J7         | Gas-mixing protection of 4-way valve                    | b2         | Malfunction of defrosting temperature sensor 1                         |
| J8         | High pressure ratio protection of system                | b3         | Malfunction of defrosting temperature sensor 2                         |
| J9         | Low pressure ratio protection of system                 | b4         | Malfunction of liquid temperature sensor of sub-cooler                 |
| JA         | Protection because of abnormal pressure                 | b5         | Malfunction of gas temperature sensor of sub-cooler                    |
| JC         | Water flow switch protection                            | b6         | Malfunction of inlet tube temperature sensor of vapor liquid separator |
| JL         | Protection because high pressure is too low             | b7         | Malfunction of exit tube temperature sensor of vapor liquid separator  |
| JE         | Oil-return pipe is blocked                              | b8         | Malfunction of outdoor humidity sensor                                 |
| JF         | Oil-return pipe is leaking                              | b9         | Malfunction of gas temperature sensor of heat exchanger                |
| P0         | malfunction of driving board of compressor              | bA         | Malfunction of oil-return temperature sensor 1                         |
| P1         | Driving board of compressor operates abnormally         | bH         | Clock of system is abnormal  |
| P2         | Voltage protection of driving board power of compressor | bE         | Malfunction of inlet tube temperature sensor of condenser              |
| P3         | Reset protection of driving module of compressor        | bF         | Malfunction of outlet tube temperature sensor of condenser             |
| P4         | Drive PFC protection of compressor                      | bJ         | High-pressure sensor and low-pressure sensor are connected reversely   |
| P5         | Over-current protection of inverter compressor          | bP         | Malfunction of temperature sensor of oil-return 2                      |

| Error Code | Content  | Error Code | Content   |
|------------|--|------------|---|
| P6         | Drive IPM module protection of compressor                    | bU         | Malfunction of temperature sensor of oil return 3         |
| P7         | Malfunction of drive temperature sensor of compressor        | bb         | Malfunction of temperature sensor of oil return 4         |
| P8         | Drive IPM high temperature protection of compressor          | H0         | Malfunction of driving board of fan                       |
| P9         | Desynchronizing protection of inverter compressor            | H1         | Driving board of fan operates abnormally                  |
| PA         | Malfunction of drive storage chip of compressor              | H2         | Voltage protection of driving board power of fan          |
| PH         | High-voltage protection of compressor's drive DC bus bar     | H3         | Reset protection of driving module of fan                 |
| PC         | Malfunction of current detection circuit drive of compressor | H4         | Drive PFC protection of fan                               |
| PL         | Low voltage protection for DC bus bar of drive of compressor | H5         | Over-current protection of inverter fan                   |
| PE         | Phase-lacking of inverter compressor                         | H6         | Drive IPM module protection of fan                        |
| PF         | Malfunction of charging loop of driven of compressor         | H7         | Malfunction of drive temperature sensor of fan            |
| PJ         | Failure startup of inverter compressor                       | H8         | Drive IPM high temperature protection of fan              |
| PP         | AC current protection of inverter compressor                 | H9         | Desynchronizing protection of inverter fan                |
| PU         | AC input voltage of drive of inverter compressor             | HA         | Malfunction of drive storage chip of inverter outdoor fan |
| F0         | Main board of ODU is poor                                    | HH         | High-voltage protection of fan's drive DC bus bar         |
| F1         | Malfunction of high-pressure sensor                          | HC         | Malfunction of current detection circuit of fan drive     |
| F3         | Malfunction of low-pressure sensor                           | HL         | Low voltage protection of bus bar of fan drive            |
| F5         | Malfunction of discharge temperature sensor of compressor 1  | HE         | Phase-lacking of inverter fan                             |
| F6         | Malfunction of exit-tube temperature sensor                  | HF         | Malfunction of charging loop of fan drive                 |
| F7         | Malfunction of humidity sensor                               | HJ         | Failure startup of inverter fan                           |
| F8         | Malfunction of water temperature sensor                      | HP         | AC current protection of inverter fan                     |
| F9         | Malfunction of jumper cap                                    | HU         | AC input voltage of drive of inverter fan                 |
| FA         | Web address of IDU is abnormal                               | —          | —   |

## Debugging:

| Error Code | Content   | Error Code | Content   |
|------------|---|------------|---|
| U0         | Preheat time of compressor is insufficient                                    | C6         | Alarm because ODU quantity is inconsistent                      |
| U2         | Wrong setting of ODU's capacity code/jumper cap                               | C7         | Abnormal communication of converter                             |
| U3         | Power supply phase sequence protection  | C8         | Emergency status of compressor                                  |
| U4         | Refrigerant-lacking protection  | C9         | Emergency status of fan   |
| U5         | Wrong address for driving board of compressor                                 | CA         | Emergency status of module                                      |
| U6         | Alarm because valve is abnormal   | CH         | Rated capacity is too high                                      |
| U8         | Malfunction of pipeline for IDU   | CC         | No main unit  |
| U9         | Malfunction of pipeline for ODU   | CL         | The matching ratio of rated capacity for IDU and ODU is too low |
| UC         | Setting of main IDU is succeeded  | CE         | Communication malfunction between mode exchanger and IDU        |
| UL         | Emergency operation DIP switch code of compressor is wrong                    | CF         | Malfunction of multiple main control units                      |
| UE         | Charging of refrigerant is invalid  | CJ         | Address DIP switch code of system is shocking                   |
| UF         | Identification malfunction of IDU of mode exchanger                           | CP         | Malfunction of multiple wired controller                        |
| C0         | Communication malfunction between IDU, ODU and IDU's wired controller         | CU         | Communication malfunction between IDU and the receiving lamp    |
| C1         | Communication malfunction between main control and DC-DC controller           | Cb         | Overflow distribution of IP address                             |
| C2         | Communication malfunction between main control and inverter compressor driver | Cd         | Communication malfunction between mode exchanger and ODU        |
| C3         | Communication malfunction between main control and inverter fan driver        | Cn         | Malfunction of network for IDU and ODU of mode exchanger        |
| C4         | Malfunction of lack of IDU  | Cy         | Communication malfunction of mode exchanger                     |
| C5         | Alarm because project code of IDU is inconsistent                             | —          | —   |

Status:

| Error Code | Content  | Error Code | Content  |
|------------|--|------------|--|
| A0         | Unit waiting for debugging                       | Ay         | Shielding status                                     |
| A2         | Refrigerant recovery operation of after-sales    | n0         | SE operation setting of system                       |
| A3         | Defrosting                                       | n3         | Compulsory defrosting                                |
| A4         | Oil-return                                       | n4         | Limit setting for max. capacity/output capacity      |
| A6         | Heat pump function setting                       | n5         | Compulsory excursion of engineering code of IDU      |
| A7         | Quiet mode setting                               | n6         | Inquiry of malfunction                               |
| A8         | Vacuum pump mode                                 | n7         | Inquiry of parameters                                |
| AH         | Heating  | n8         | Inquiry of project code of IDU                       |
| AC         | Cooling  | n9         | Check quantity of IDU on line                        |
| AL         | Charge refrigerant automatically                 | nA         | Heat pump unit                                       |
| AE         | Charge refrigerant manually                      | nH         | Heating only unit                                    |
| AF         | Fan  | nC         | Cooling only unit                                    |
| AJ         | Cleaning reminding of filter                     | nE         | Negative code  |
| AP         | Debugging confirmation when starting up the unit | nF         | Fan model  |
| AU         | Long-distance emergency stop                     | nJ         | High temperature prevention when heating             |
| Ab         | Emergency stop of operation                      | nU         | Eliminate the long-distance shielding command of IDU |
| Ad         | Limit operation                                  | nb         | Bar code inquiry                                     |
| An         | Child lock status                                | nn         | Length modification of connection pipe of ODU        |

**NOTICE!** For detailed malfunction and maintenance, please refer to the engineering debugging and after-sales maintenance manual.

## 8 Maintenance and Care

Regular check, Maintenance and care should be performed every six months by professional personnel, which will prolong the unit life span. Disconnect the power supply before cleaning and maintenance.

### 8.1 Outdoor Heat Exchanger

Outdoor heat exchanger is required to be cleaned once every six months. Use vacuum cleaner with nylon brush to clean up dust and sundries on the surface of heat exchanger. Blow away dust by compressed air if it is available. Never use water to wash the heat exchanger.

### 8.2 Drain Pipe

Regularly check if the drain pipe is clogged in order to drain condensate smoothly.



### 8.3 Notice before Seasonal Use

- (1) Check if the inlet/outlet of the indoor/outdoor unit is clogged.
- (2) Check if the ground wire is earthed reliably.
- (3) Check if battery of remote wireless controller has been replaced.
- (4) Check if the filter screen has been set soundly.
- (5) After long period of shutdown, open the main power switch 8 hours before operating the unit so as to preheat the compressor crankcase.
- (6) Check if the outdoor unit is installed firmly. If there is something abnormal, please contact the GREE appointed service center.

### 8.4 Maintenance after Seasonal Use

- (1) Cut off main power supply of the unit.
- (2) Clean filter screen and indoor and outdoor units.
- (3) Clean the dust and sundries on the indoor and outdoor units.
- (4) In the event of rusting, use the anti-rust paint to stop spreading of rust.

### 8.5 Parts Replacement

Purchase parts from Gree appointed service center or dealer if necessary.

#### **NOTICE!**


During airtight and leakage test, never mix oxygen, ethyne and other dangerous gas into refrigeration circuit. In case of hazard, it's better to use nitrogen or refrigerant to accomplish such test.

## 9 After-sales Service

In case the air-conditioning unit you bought has any quality problem or you have any inquiry, please contact the local after-sales service agency designated by Gree.

Warranty should meet the following requirements:

- (1) First run of the unit should be operated by professional personnel from Gree appointed service center.
- (2) Only Gree manufactured accessories can be used on the machine.
- (3) All the instructions listed in this manual should be followed.
- (4) Warranty will be automatically invalid if fails to obey any item mentioned above.



**GREE ELECTRIC APPLIANCES, INC. OF ZHUHAI**

Add: West Jinji Rd, Qianshan, Zhuhai, Guangdong, China, 519070

Tel: (+86-756) 8522218

Fax: (+86-756) 8669426

E-mail: [global@cn.gree.com](mailto:global@cn.gree.com) [www.gree.com](http://www.gree.com)



600005000669